

PART NO.	DESCRIPTION	PLATE NO.	REMARKS	QTY. REQ.
	VERTICAL LINK - Early vehicles only			
20337	Upper ball joint assembly	B1/ 1		2
	Grease nipple	B1/-2		2.
	Upper ball joint	B1/3		2
	Rubber gaiter	B1/ 4		2
	Washer	B1/ 5		2
	Nyloc nut	B1/ 6		2
203365	Vertical link, L.H	B1/ 7		. 1
203364	Vertical link, R.H			1
203378	Trunnion, L.H	B1/8		1
203377	Trunnion, R.H			1
4854	Grease nipple, trunnion	B1/ 9		2
203374	Grease seal, trunnion	B1/10		2
203368	Tie rod lever, L.H	B1/11		1
203367	Tie rod lever, R.H			. 1
204556	Distance piece, tie rod lever	B1/12		4 .
203383	Lockwasher, tie rod lever	B1/13		4
50088	Bolt, long, tie rod to vertical link	B1/14		2
50087	Bolt, short, tie rod to vertical link	B1/15		2
203366	Stub axle shaft	B1/16		2.
20021	Felt seal	B1/17		2
	⊶ Cover, felt seal	B1/18		2






PART NO.	DESCRIPTION .	PLATE NO.	REMARKS	QTY. REQ.
	VERTICAL LINK - continued			
204324	Water shield, inner, front hub (Early vehicles only) .		• • • • • • • • • • • • • • •	2
205302	Water shield, inner, front hub	B1/19	• • • • • • • • • • • • • •	2
204022	Washer, stub axle shaft	B1/20	• • • • • • • • • • • • • • • • •	2
50869	Nyloc nut, stub axle shaft			2
200209	Taper Bearing, inner	B1/22		2
200208	Hub assembly c.w. studs	B1/23		2
200255	Stud, hub:	B1/24	• • • • • • • • • • • • • • • • • • • •	8
200210	Taper bearing, outer	B1/25		2
200214	D washer, stub axle	B1/26		2
200215	Split pin, stub axle	B1/27		2
200213	Slotted nut	B1/28		2
200216	Hub cap	B1/29		2








PART NO.	DESCRIPTION	PLATE NO.	REMARKS	QTY. REQ.
	WISHBONES AND DAMPER - Early vehicles only			
03369	Fulcrum, upper wishbone	B2/ 1		2
201904	Spacer, camber adjustment	B2/ 2		As Reg*d
7143	Shim, camber adjustment	B2/ 3		As Reg'd
0087B	Bolt. top, fulcrum to frame	B2/ 4		4
0088B	Bolt. lower, fulcrum to frame			4
C843B	Nut, fulcrum to frame	B2/ 5		8
03370	Wishbone, front upper	B2/6		2
03371	Wishbone, rear upper	B2/ 7		2
03375	Rubber bush, upper fulcrum	B2/ 8		8
04021	Plain washer, upper fulcrum	B2/ 9		. 4
50763	Slotted nut, upper fulcrum	B2/10		4
53887	Split pin, upper fulcrum	B2/11		4
50088	Bolt, wishbones to upper ball housing	B2/12		4
50843	Nyloc nut, wishbones to upper ball housing	B2/13		4
04023	Washer, wishbones to upper ball housing	B2/14	• • • • • • • • • • • • • • • • • • • •	4
33381	Wishbone, lower, L.H. rear and R.H. front	B2/15		2
03380	Wishbone, lower, R.H. rear and L.H. front	B2/16	• • • • • • • • • • • • • • • • • • • •	2
4854	Greaser, lower wishbones to trunnion	B2/17		4
03384	Grease seal, lower wishbones to trunnion	B2/18		8
03382	Thrust washer, lower wishbones to trunnion	B2/19		8
04497	Tabe, lower wishbones to trunnion	B2/20		4

PART NO.	DESCRIPTION	PLATE No.	REMARKS	QTY. REQ.
	WISHBONES AND DAMPER - continued		•	•
203383	Lockwasher, lower wishbones to trunnion	B2/21	• • • • • • • • • • • • • • • • •	4
50763	Slotted nut, lower wishbones to trunnion	B2/22	• • • • • • • • • • • • • • •	4
53887	Split pin, lower wishbones to trunnion	B2/23	• • • • • • • • • • • • • • • •	4
204607	Bush, lower wishbone pivot	B2/24	************	4
204516	Bracket, lower wishbone pivot	B2/25	• • • • • • • • • • • • • • • • • • • •	4
50165B	Bolt, wishbone to pivot bracket	B2/26	• • • • • • • • • • • • • • • • • • • •	4
50885B	Nut, bolt securing	B2/27	• • • • • • • • • • • • • • • • • • • •	4
50843B	Nut, pivot bracket to frame	B2/28 -		· 8 .
204331	Bracket, lower wishbone to damper	B2/29	• • • • • • • • • • • • • • • • • • • •	2
50086B	Bolt, front, wishbone to bracket	B2/30		4
50085B	Bolt, rear, wishbone to bracket	B2/31	• • • • • • • • • • • • • • • • • • • •	4
200892	Spacer, wishbone to bracket	B2/32		As Req
50883B	Nut, wishbone to bracket	B2/33		4
50164B	Bolt, damper lower to bracket and damper top to frame.	B2/34	• • • • • • • • • • • • • • • • • • • •	4
50885B	Nut, damper lower to bracket and damper top to frame	B2/35		4
204332	Damper unit assembly	B2/36	• • • • • • • • • • • • • • • • • • • •	2
12117	Bush, ferrule	B2/37		4
12115	Spring	B2/38		2
12025	Retainer, spring	B2/39		2
				_








ART NO.	DESCRIPTION	PLATE NO.	REMARKS	QTY REQ
	FRONT SUSPENSION - Later vehicle only			
05447	Front suspension unit assembly R.H		•••••	1
05448	Front suspension unit assembly L.H.		***************************************	1
06010	Vertical link, R.H.	B3/1	• • • • • • • • • • • • • • • • • • • •	
06011	Vertical link, L.H	-5, ,	•••••••••••	,
05027	Upper ball joint	B3/ 2	***************	.'
0843C	Nyloc nut, upper ball joint	B3/3		2
04023	Washer, nut, upper ball joint	B3/ 4		2
05028	Greaser, vertical link	B3/ 5		2
03367	Tie rod lever, R.H.	.B3 / 6		1
03368	Tie rod lever, L.H	.50,		1
0843C	Nyloc nut, tie rod lever	B3/ 7		Ŕ
06013	Caliper plate, R H.	B3/8		1
06014	Caliper plate, L.H			i
03376	Tab washer, plate to vertical link	B3/ 9		4
0082B	Bolt, plate to vertical link 1.3/8 inch	B3/10	• • • • • • • • • • • • • • • • • • • •	2
520B	Bolt, plate to vertical link % inch	B3/11		2
0089B	Bolt, plate to link and lever 3 inch	B3/12		2
06023	Bolt, plate to link and lever 3.3/8 inch	B3/13		2
06012	Stub axle shaft	B3/14		2
D843B	Nyloc nut, stub axle shaft	B3/15		. 2
11359	Plain washer stub axle shaft	B3/16		2
06 02	Oil seal, stub axle shaft	B3/17		2



PART NO.	DESCRIPTION	PLATE NO.	REMARKS	QT'
	NEW SUSPENSION - continued			
06020	Bearing, inner, stub axle shaft	B3/18		2
08021	Bearing, outer, stub axle shaft	B3/19	• • • • • • • • • • • • • • • • • • • •	2
06022	'D' washer, stub axle shaft	B3/20	•••••	2
50764	Slotted nut, stub axle shaft	B3/21	• • • • • • • • • • • • • • • • • • • •	2
53886	Split pin, stub axle shaft	B3/22	• • • • • • • • • • • • • • • • • • • •	2
05450	Hub and stud assembly		,	2
05451	Hub	B3/24	• • • • • • • • • • • • • • • • • • • •	Z
05452	Stud	B3/25	•	2
06 01 9	Hub cap	B3/26 B3/27	*************	1
06025	Trunnion assembly L.H	53/21		7
06026	Washer, trunnion	B3/28		Ŕ
06030	Spacer, trunnion	B3/28		Ä
06032 06031	Rubber seal, trunnion	B3/28		A
	Slotted nut, trunnion	B3/30		2
06033 06018	Grease seal, trunnion	B3/32		2
06018	Wishbone assembly, rear R.H. and front L.H	03/02		2
06035	Wishbone arm, rear R.H. and front L.H	B3/33		2
06035	Water shield	B3/34		4
06036 06037	Nylon bearing	B3/35		4
04607	Bush	B3/36		2
08040	Wishbone assembly, rear L.H. and front R.H	B3/37		2
06038	Wishbone arm, rear L.H. and front R.H.			2
06036	Water shield			
06 03 7	Nylon bearing	. •		1
00 03 7 04 6 0 7	Bush	* .		
05428	Mounting bracket, lower wishbone	B3/38		1:17
03428 0843B	Nut, bracket to frame	B3 /3 9		
0165B	Bolt, wishbone to bracket	B3/40		
08858	Nut. wishbone to bracket	: 83/41		
05428	Bracket, lower wishbones to damper	B3/42		
0086B	Bolt, lower wishbones to damper bracket	B3 /43		
0085B	Bolt, lower wishbones to damper bracke'			4
0883B	Nut, lower wishbones to damper 'bracket	B3/44		. (
08029	Bolt, lower wishbones to damper trunnion	B3/45		
04332	Damper unit assembly			2
12117	Bush ferrule	-B3/46		
12115	Spring	·B3/47		:
12025	Retainer, spring	B3/48		
12023	Sunnort spring	B3/49		
0184B	Bolt, damper to mounting bracket and frame	B3/50		
0885B	Nut, damper to mounting bracket and frame	B3/51		
06016	Upper wishbone, front	83/52		
06 01 7	Upper wishbone, rear	B3/53		
0088B	Bolt, upper wishbones to ball housing	B3/54		4
0843 Ç	Nyloc nut, upper wishbones to ball housing	B3/55		
04023	Washer, upper wishbones to ball housing	B3/56		
03369	Upper fulcrum	B3/57		
03375	Rubber bush, upper fulcrum to wishbones	B3/58		
04021	Plain washer, upper fulcrum to wishbones	B3/59		
50763	Slotted nut, upper fulcrum to wishbones	B3/60		
53887	Split pin, upper fulcrum to wishbones	B3/É1		
01904	Spacer, camber adjustment	B3/82		As R
7143	Shim, camber adjustment	B3/63	•••••	As R
0087B	Bolt, fulcrum to spacer, top	83/64	• • • • • • • • • • • • •	
0088B	Bolt, fulcrum to spacer, bottom	B3/65		·. :
0843B	Nut, fulcrum to spacer	B3/66		
06 03 4	Bracket, brake hose	B3/67		
	Bolt, hub to disc	83/88		
1522C	Spring washer, hub to disc	B3/69		- 3
1203B	Dust cover, R.H.	D2 /70		
05429		•		
05430	Dust cover, L.H.	B3/71	* * * * * * *	121
0843B	Nyloc nut, dust cover	B3/71		1 1 72
04 022	Plain washer, dust cover	03/12		
04 023 062 96	Spacer, tie rod	B3/73		•






PART NO.	DESCRIPTION	PLATE No.	REMARKS	QTY. REQ.
	ANTI-ROLL BAR - All vehicles			
204375_	Anti-roll bar	B4/ 1	• • • • • • • • • • • • • • • • • • • •	1
0445	Mounting bracket, anti-roll bar		• • • • • • • • • • • • • • • • • • • •	2,
0446	Mounting rubber, anti-roll bar	B4/ 3	••••••	2
01662	Spacer	B4/ 4	• • • • • • • • • • • • • • • • • • • •	4
1132E	Washer, mounting bracket fixing	B4/ 5	• • • • • • • • • • • • • • • • • • • •	4
0842B	Nut, mounting bracket fixing	.B4/6	• • • • • • • • • • • • • • • • • • • •	4
104451	Link, anti-roll bar	B4/7	• • • • • • • • • • • • • • • • • • • •	2
204355	Mounting bracket R.H	B4/8	• • • • • • • • • • • • • • • • • • • •	1
204356	Mounting bracket L.H			1





Rear Suspension



PART NO.	DESCRIPTION	PLATE No.	REMARKS	QTY. REQ.
			•	và r
	REAR SUSPENSION			
204429	Rear suspension assembly	•		1
204633	Spring and damper unit	•		2
12107	Damper	. C1/1		2
12117	Ferrule rubber, damper	. C1/2		4
12116	Spring	. C1/3		2
12025	Spring retainer	. C1/4		2
12111	Support ring, spring	. C1/5		2'
200004	Bracket, damper fixing, top	. C1/6		2
50088B	Bolt, bracket to frame	. C1/7		4
50883B	Nut, bracket to frame	. C1/8	• • • • • • • • • • • • • • • • • • • •	4
50164B	Bolt, damper to top bracket	. C1/9		2
50885B	Nut, damper to top bracket	. C _{1/10}		2.
204334	Bracket, damper dixing, lower L.H	. C1/11		1
2 04335	Bracket, damper fixing, lower R.H	•		1
200399	Bolt, damper to lower bracket	. C1/12		2
4096	Washer, damper to lower bracket	. C1/13		4
50885B	Nut, damper to lower bracket	. C1/14		2
200001	"U" bolt, axle to lower damper bracket	. C1/15		4
201279	Location plate, 'U' bolt	. C1/16		2
50963N	Nut, 'U' bolt	. C1/17		8.
204370	Radius arm assembly	. C1/18		4
204473	Radius arm	. C1/19		4
204442	Bush, radius erm, front	. C1/20		4






Rear Suspension



PAR.	DESCRIPTION	PLATE NO.	REMARKS	QTY. REQ.
	REAR SUSPENSION - continued			
50205B	Bolt, radius arm axle, rear top pivot	C1/22		2
50206B	Bolt, radius arm axle lower and front top pivot	C1/23	• • • • • • • • • • • • • • • • • • • •	6
50906B	Nut, radius arm bolts	C1/24		8
204180	Cantilever arm	C1/25		1 .
204186	Radius arm assembly, transverse	C1/26		2
204036	Transverse radius arm	C1/27	• • • • • • • • • • • • • • • • • • • •	2
200048	Bush	C1/28	********	4
501248	Bolt, radius arm fixing	C1/29		4
50884B	Nut, radius arm fixing	C1/30		4
204047	Gear carrier cover strap	C1/31		1
50226B	Bolt, cover strap to cantilever arm	C1/32		1
51126B	Washer, cover strap to cantilever arm	C1/33		i
204065	Tab washer, cover strap to cantilver agm	C1/34	•••••••	1
51502B	Set screw, cover strap	C1/35		4
51202B	Lockwasher, cover strap			4








PART NO.	DESCRIPTION	PLATE NO.	REMARKS	QTY REQ
	STEERING COLUMN			
204711	Steering wheel	D1/ 1	•••••	1
205245	Boss, steering wheel	D1/ 2		1
200 4 02	Nut, boss to steering column	D1/3		•
2017/86	Screw, steering wheel to boss	D1/ 4		5
203128	Steering wheel centre	D1/ 5		1
203298	Motif, steering wheel centre	D1/6		1
203299	Nut, motif fixing	D1/7		1
203122	Striker assembly, indicator switch return			1
203294	Strike boss	D1/8		1
203295	Peg, long	D1/ 9		1
203296	Peg. short	D1/10		1
203125	Grub screw, striker locking	01/11		1
203121	Bush, striker	D1/12		1
205246	Upper steering column, inner	D1/13		1
204648	Lower steering column	D1/14		1
204659	Universal joint	D1/15		1
50042B	Bolt, steering column pinch	D1/16		3
510028	Nut, steering column pinch	D1/17		3
204792	Bush, lower steering column support	D1/18		1
54170K	Rivet, bush to frame	D1/19		2
2 0 4 6 9 2	Upper steering column, outer	D1/20		1





PA NO.	DESCRIPTION	PLATE NO.	REMARKS	QTY. REQ.
	COLUMN AND WHEEL - continued			
202877	Bush, steering column	D1/21		. 2
202879	Washer, bush retaining			4
202878	Circlip, bush retaining	D1/23		2
51522B	Set screw	D1/24		2
201662	Spacer	D1/25		2
51123B	Washer	D1/26		2
51203B	Lockwasher	D1/27	•	2
5 0 6 8 3 B	Nut	D1/28	*************	2
204838	Location tube, steering column, (bonded into body)	D1/28	••••••	2
54767	Clip, steering column location tube	D1/29	• • • • • • • • • • • • • • • • • • • •	1





PART NO.	DESCRIPTION	PLATE NO.	REMARKS	QTY. REQ.
	RACK AND PINION			
202569	Rack and pinion assembly		R.H.D. only	1.
202572	Rack and pinion assembly	•	L.H.D. only	1
205035	. Body	D2/ 1	R.H.D. only	1
205036	Body		L.H.D. only	1
205043	Pinion	D2/ 2	R.H.D. only	1
205044	Pinion		L.H.D. only	1
205041	Thrust washer, pinion	D2/ 3		1
205042	Bush, pinion	D2/ 4		1
205039	Cover, pinion end	D2/ 5		1
205045	Thrust washer, pinion	D2/6		1
205046	Bush, pinion	D2/ 7		1
205047	Shim, pinion, .003" thick	D2/8		As req
205048	Shim, pinion, .010° thick		• • • • • • • • • • • • • • • • • • • •	As req
205049	'O' Ring, pinion	D2/ 9		1
205050	Plug, pinion end	D2/10	• • • • • • • • • • • • • • • • • • • •	
205052	Circlip, pinion end	D2/11		1
205053	Thrust button	D2/12		1
205054	Spring, thrust button	D2/13		1
205055	Shim, thrust button, .022 thick	D2/14		As req
205056	Shim, thrust button, .004" thick			As req
205057	Shim, thrust button, .010" thick			As req
205058	Cap	D2/15		1.
205059	Plug	D2/16		1






PART NO.	DESCRIPTION	PLATE NO.	REMARKS	QTY. REQ.
	RACK AND PINION - continued			
205040	Rack	D2/17	• • • • • • • • • • • • • • • • • • • •	1
205069	Locknut, rack	D2/18	• • • • • • • • • • • • • • • • • • • •	2
205067	Sleeve nut, rack	D2/19	• • • • • • • • • • • • • • • • • • • •	2
205064	Tab washer, rack	D2/20	• • • • • • • • • • • • • • • • • • • •	` 2
205068	Spring, rack	D2/21	• • • • • • • • • • • • • • • • • • • •	2
205065 205066	Shim, .002" thick	D2/22	• • • • • • • • • • • • • • • • • • • •	
205063	Socket, ball	D2/23	•••••••••••	Ąs red'd.
205062	Outer tie-rod	D2/23	••••••	2
205061	Cup nut, outer tie rod	D2/24 D2/25	• • • • • • • • • • • • • • • • • • • •	2
10707B	Locknut, outer tie rod		• • • • • • • • • • • • • • • • • • • •	2
05075	Ball joint assembly, outer	D2/26	• • • • • • • • • • • • • • • • • • • •	2
5636		02/27	• • • • • • • • • • • • • • • • • • • •	2
205076	Grease nipple, outer ball joint	D2/28	• • • • • • • • • • • • • • • • • • • •	2
205076	Rubber gaiter, outer ball joint	D2/29	• • • • • • • • • • • • • • • • • • • •	2
	Retainer, rubber gaiter	D2/30	••••••••••••	2
1135B	Washer	D2/31	• • • • • • • • • • • • • • • • • • • •	2
0845B	Nut	D2/32		2
05070	Rubber gaiter, L.H	D2/33	• • • • • • • • • • • • • • • • • • • •	1
05072	Clip, gaiter fixing	D2/34	• • • • • • • • • • • • • • • • • • • •	2
05074	Wire, gaiter fixing	D2/35	• • • • • • • • • • • • • • • • • • • •	As req'd.
05 07 1	Rubber gaiter, R.H	D2/36	• • • • • • • • • • • • • • • • • • • •	1
05073	Clip, R.H. gaiter fixing	D2/37	• • • • • • • • • • • • • • • • • • • •	. 1
01929	Clamp, rack and pinion securing	D2/38		2 ,
01933	Mounting rubber, rack and pinion assembly	D2/39	• • • • • • • • • • • • • • • • • • • •	2
204057	Shim, rack and pinion mounting	D2/40		2
03680	Locking plate, rack and pinion mounting	D2/41		2
0842B	Nut, rack and pinion fixing	D2/42	· · · · · · · · · · · · · · · · · · ·	4
1132B	Washer, rack and pinion fixing	D2/43		4



Cooling System




PART NO.	DESCRIPTION	PLATE NO.	REMARKS	QTY. REQ.
	RADIATOR AND HOSES			
204420	Radiator assembly c.w. cap and drain tube	E1/ 1		1
201156	Jap, radiator drain	E1/ 2		1
51502B	Bolt, radiator to frame	E1/ 3		3
51202B	Lockwasher, radiator to frame	E1/ 4		3
51132B	Washer, radiator to frame	E1/ 5		3
204639	Elbow hose, engine to tube	E1/6		•
204748	Tube, engine to radiator			1
204409	Hose, tubes to radiator	E1/8		2
204389	Tube, radiator to pump	E1/ 9		!
51481B	Bolt, tube fixing	_		2
51002	Nut, tube fixing	E1/11		2
204388	Hose, tube to pump	E1/12		1
200973	Clip, hoses	E1/13		8

E 2


Cooling System





PART NO.	DESCRIPTION	PLATE No.	REMARKS	QTY. REQ.
	WATER PUMP			
205957	Pump, water assembly		2724E-8501C	1
205958	Kit, pump repair		2724E-8591A	i
205959	Cap, heater blanking	E2/ 1	2724E-8K501A	1
205960	Clamp heater blanking	E2/ 2	114807-ES7/8	i
205961	Gasket	E2/3	2724E-8507A	1
205962	Pulley		2724E-8509A	1
205963	Gasket, pump cover	E2/ 5	2724E-8513A	i
205964	Bearing	E2/ 6	2724E-8530B	·
205965	Slinger	E2/ 7	2724E-8550B	i
2054 <u>0</u> 4	Blade, fan	E2/ 8	2724E-8600B	i
	Bolt	E2/ 9	20324-\$7/B	Å
10420	Washer	E2/10	44719-87/8	· 🔏
2003 <u>24</u>	Lockwasher	E2/11	34806-S7/8	Ā
2 0 5	Belt, fan205219	E2/12	2724E-8A602A	1
2 05 9 5 7	Hub, fan, assembly	E2/13	2724E-8616B	1
51501B	Bolt, hub to crankshaft	E2/14	20326-\$7/8	4
200324	Lockwasher	E2/15	34806-S7/8	4





PART NO.	DESCRIPTION	PLATE NO.	REMARKS	QTY.
	ENGINE - EXTERIOR			
205500	Block, cylinder assembly	F1/ 1	2721E-6010-A	1
205501	Dowel, cylinder head to cylinder block	F1/2	2724E-6A008-A	4
205502	Plug. cylinder block cross drilling	F1/3	87835-\$	4
205503	Plug, cylinder block main oil gallery	F1/4	87837-ES2	5
205504	Plug, cylinder block sides and front expansion	F1 ' 5	115476-FS	6



Engine




PAN NO.	DESCRIPTION	PLATE NO.	REMARKS	QTY. REQ.
	EXTERIOR - continued			
202167	Plug, cylinder block rear expansion	F1/6	353000-S	1
205506	Cylinder assembly complete 2.5 litre		2721E-6011B	. 1
205507	Cylinder assembly complete 3 litre		2725E-6011B	1
205508	Cover assembly, cylinder front	F1/7	2721E-6019A	1
205509	Stud, fuel pump to front cover	F1/8	88371-\$	2
205553	Bolt, front cover to back plate	F1/ 9	20512-\$2	4
50066B	Bolt, front cover to cylinder block	F1/10	20520-\$2	7
51222B	Lockwasher, front cover bolt	F1/11	34826-\$	11
205513	Gasket, front cover	F1/12	2724E-6020A	1
205514	Gasket, cylinder head	F1/13	2721E-6051A	2
205515	Sleeve, cylinder block distributor bore	F1/14	2724E-6K051A	1
205516	Sleeve, cylinder block distributor bore 0.015 inch 0/S	F1 /15	2724E-6K051B	1
205517	Plug, cylinder block water drain	F1/15	2724E-6K053A	1
205518	Washer, plug, cylinder block water dráin	F1/16	112304-ES	6
05519	Sleeve, cylinder block	F1/17	2724E-6055A 2724E-6055B	6
205520	Sleeve, cylinder block 0.020 inch 0/S	F1/18	2724E-6065A	16
205554		F1/18	2724E-6B070A	1
205	Plate, cylinder front cover	F1/19 F1/20	2724E-8B055	1
205523	Stiffener, front	F1/20	2724E-6K080B	1
05525 05555	Bolt, stiffener to cylinder block	F1/22	111543-ES	3
05555 05524	Cylinder head assembly	F1/23	2721E-6085A	2
05524 05504	Plug cylinder head expansion	F1/24	115478-ES	ī
05528	Plug, cylinder head expansion	F1/25	119778-ES	1
05527	Plug, cylinder head	F1/28	87840-S	4
05527	Bush, valve guide		2724E-8510A/B	24
05529	Seal assembly, crankshaft, front	F1/28	2724E-6362A	1
05530	Plate, engine rear cover	F1/29	2724E-6A373A	. 1
05531	Gasket, crankshaft rear bearing	F1/30	2724E-6344A	1
05556	Bolt, plate to cylinder block	F1/31	20310-\$7/8	1
05557	Bolt, plate to cylinder block		20346-\$7/8	1
05532	Cover assembly, L.H. valve rocker arm	F1/32	2721E-6A505-A	1
05533	Cover assembly, R.H. valve rocker arm		2721E-6582-B	1
05558	Screw, cover to cylinder head	F1/33	50527-\$7/8	12
02250	Washer, cover to cylinder head	F1/34	118297-S	12
05559	Screw, cover to cylinder head and inlet manifold		111578-ES2	12
05374	Gasket, cover, valve rocker arm	F1/35	2721E-6584A	2
05535	Valve assembly, crankcase ventilator	F1/36	2721E-6A666	1
05528	Sump assembly engine oil	F1/37	2721E-6675A	1
05	Plug, sump drain	F1/38	2724E-6730A	1
05538	Gasket, sump drain	F1/39	2724E-6374A	1.
055	Screw assembly, sump to cylinder block	F1/40	42906-\$8	. 6
055	Screw assembly, sump to cylinder block	F1/41	43263-\$8	2
105512	Screw assembly, sump location tubes		43511-S	2
02250	Washer, sump to cylinder block	F1/42	118297-ES2	2 4
25540	Filter assembly c.w. gasket, oil	F1/43	2724E-6714B	1
05541	Dipstick, oil level	F1/44	2721E-6750A	1
05542	Gasket, dipstick	F1/45	E1ADKN-6761	1
35543	Tube, dipstick	F1/46	2721E-6754A	i
25544	Cap. oil filler	F1/47	2724E-6766A	2
05545	Insert, filter mounting bolt		2724E-6890A	1
	Gasket block to sump, set	F1/48	2721E-6781 A	1

F 2







PART NO.	DESCRIPTION	PLATE NO.	REMARKS	QTY. REQ.
	ENGINE INTERIOR			
05571	Piston, pin & rings assembly	Fo / 1	2724E-6102A	-∶6
105572	Piston pin & rings assembly .0025 0/S		2724E-6102B	6
205573	Piston, pin & rings assembly .015 0/S		2724E-6102C	6
205574	Piston, pin & rings assembly .030 0/S		2724E-6102D	6
205575	Piston, pin & rings assembly .045 0/S		2724E-6102E	6
205576	Piston, pin & rings assembly .060 0/S	• • • •	2724E-6102F	6
205577	Piston standard		2721E-8110A	6
205578	Piston .0025 0/\$	••••	2721E-6110B	6
205579	Piston .015 O/S	• • • •	2721E-6110C	6

F 2

Engine



PAN NO.	DESCRIPTION	PLATE NO.	REMARKS	QTY. REQ.
	INTERIOR - continued		·	
205580	Piston .030 0/S		2721E-6110D	6
205581	Piston .045 0/S		2721E-6110E	6
205582	Piston .060 0/S		2721E-6110F	6
205583	Pin piston	F2/ 3	2724E-6135A	6
205584	Ring set, piston standard	F2/4	2724E-6148A	6
205585	Ring set, piston .0025 0/S		2724E-6148B	6
205586	Ring set, piston .015 O/S		2724E-6148C	6
205587	Ring set, piston .030 O/S		2724E-6148D	6
205588	Ring set, piston .045 O/S		2724E-6148E	6
205589	Ring set, piston .060 O/S		2724E-6148F	6
205590	Rod connecting assembly	F2/ 5	2724E-6200B	6
205591	Bearing connecting rod standard	F2/ 6	2724E-6211B	12
205592	Bearing connecting rod .002 U/S		2724E-6211C	12
205593	Bearing connecting rod .010 U/S		2724E-6211D	12
205594	Bearing connecting rod .020 U/S		2724E-6211E	12
205595	Bearing connecting rod .030 U/S		2724E-6211F	12
205596	Bearing connecting rod .040 U/S		2724E-6211G	12
205	Camshaft	F2/ 7	2721E-6250A	2
205	Gear assembly camshaft	F2/8	2724E-6256B	2
205599	Key Gear to camshaft	F2/ 9	115016-ES	2
205741	Bolt, camshaft to gear	F2/10	20411-82	2
205600	Eccentric fuel pump driving	F2/11	2724E-6287B	1 .
205601	Bearing camshaft front standard	F2/12	2724E-6261C	2
205602	Bearing camshaft front .020 O/S		2724E-6261D	2
205603	Bearing camshaft centre standard	F2/13	2724E-6262C	2
205604	Bearing camshaft centre .020 O/S		2724E-6262D	2
205605	Bearing camshaft intermediate standard	F2/14	2721E-6270C	2
205606	Bearing camshaft intermediate .020 0/S		2721E-6270D	2
205607	Spacer camshaft gear	F2/15	2724E-6265B	2
205608	Plate camshaft thrust	F2/16	2724E-6269B	2
205719	Screw plate to camshaft	F2/17	111577-\$5	4
205609	Tappet assembly	F2/18	2724E-6500A	12 6
205610	Plate valve rod guide standard holes	F2/19	2724E-6K502A	6
205611	Plate valve rod guide .382/387 dia. holes		2724E-6K502B 2724E-6K502C	6
205612	Plate valve rod guide .394/.399 dia. holes	F0 /00	20326-\$7/8	3
51501C	Bolt plate to cylinder head	F2/20	34806-\$7/8	3
51222C	Washer locking	F2/21 F2/22	2724E-6565A	12
205408	Rod, valve push	F2/22 F2/23	2724E-6505A	6
205	Valve exhaust .003 0/S	F Z / Z 3	2724E-6505B	6
205616	Valve exhaust .015 0/S		2724E-6505C	6
205616	Valve exhaust .030 O/S		2724E-6505D	6
205	Valve inlet standard	F2 '24	2724E-6507A	6
205619	Valve inlet .003 0/S	12. 24	2724E-6507B	6
255620	Valve inlet .015 0/S		272 4E-6507C	6
205621	Valve inlet .030 0/S		2724E-6507D	6
205821	Spring valves	F2/25	2724E-6513B	12
205822	Retainer valve spring	F2 26	C20E-6514A	12
202261	Lock valve spring retainer	F2/27	EOTA-6518	24
	Seal valve stem	F2 /28	C20E-6571A	1 2
205625 205626	Insert valve seat, inlet standard	F2/29	2724E-6056A	6
				_
205527	Insert valve seat .010 O/S O.D.		2724E-6056B	6
205628	Insert valve seat .010 O/S O.D. and depth		2724E-6056C	6
205629	Insert valve seat .020 0/S 0.D.		2724E-6056D	6
205530	Insert valve seat .020 O/S O.D. and depth		2724E-6056E	6
205631	Insert valve seat exhaust standard	F ₂ /30	2724E-6057A	6
205632	Insert valve seat exhaust .010 O/S O.D		2724E-6057B	6
205633	Insert valve seat exhaust .010 0/S 0.D. and depth		2724E-6057C	6
205634	Insert valve seat exhaust .020 0/S 0.D		2724E-6057D	6
205625	Insert valve seat exhaust .020 O/S O.D. and depth		2724E-6057E	6
2 0 7	Arm valve rocker	F2/31	2724E-6564A	12



Engine


F₂

PART NO.	DESCRIPTION	PLATE NO.	REMARKS	QTY. REQ.
	INTERIOR - continued			
205637	Seat valve rocker arm fulcrum	F2/32	C20Z-6A528A	12
205721	Nut valve rocker arm stud	F2/33	114368-ES2	12
205401	Crankshaft 2.5 litre	F2/34	2721E-6303A	1
205639	Crankshaft 3 litre		2725E-6303A	1
205640	Gear crankshaft	F2/35	2724E-6306A	1
205641	Key gear	F2/36	115014-ES	1
205642	Pulley crankshaft	F2/37	2721E-631·2A	1
205643	Washer pulley bolt	F2/38	2724E-6A345B	1
205741	Bolt pulley	F2/39	20411-82	1
205644	Bearing crankshaft upper standard red	F2/40	2724E-6333A	4
	Bearing crankshaft blue	. 27 40	2724E-6333C	4
205645			2724E-6333E	4
205646	Bearing crankshaft upper .015 O/S O.D010 U/S I.D. Green		2/241-03331	7
			2724E-6333G	4
205647	Bearing crankshaft upper Yellow		2724E-6333J	4
205648	Bearing crankshaft upper .015 O/S		2724E-6333L	4
205649	Bearing crankshaft upper .015 0/S		2724E-18347A	4
205650	Bearing kit - standard O.D010 U/S I.D		2724E-18347C	4
205651	Bearing kit - standard O.D020 U/S I.D		2724E-18347E	4
205652	Bearing kit - standard O.D030 U/S I.D		2724E-18347G	4
205653	Bearing kit - standard O.D040 U/S 1.D		2724E-18347J	4
205654	Bearing kit015 0/S 0.D010 U/S 1.D			
205655	Bearing kit015 O/S O.D010 U/S I.D		2724E-18347L	4
205656	Bearing kit015 O/S O.D030 U/S I.D		2724E-18347N	4
205657	Retainer rear oil seal	F2/41	2724E-6335A	1
50060	Bolt rear oil seal retaining	F2/42	112107-ES	4
	Lockwasher	F2/43	34826-S	4
205373	Bearing crankshaft lower standard Red	F2/44	2724E-6A338A	4
205659	Bearing crankshaft lower standard Blue		2724E-6A338C	4
205660	Bearing crankshaft lower .015 O/S Q.D010 U/S L.D		2724E-6A338E	4
	Green			
205661	Bearing crankshaft lower .015 O/S O.D010 U/S L.D Yellow		2724E-6A338G	4
205662	Bearing crankshaft lower .015 O/S O.D		2724E-6A338J	4
205663	Bearing crankshaft lower .015 O/S Q.Q		2724E-6A338L	4
205531	Gasket crankshaft rear oil seal	F2/45	2724E-6344A	1
205868	Bolt crankshaft bearing cap	F2/45	2724E-6345A	8
205665	Kit crankshaft main bearing thrust washer standard	F2/40 F2/47	2724E-6A355A/F	1
205666	Kit crankshaft main .0025 O/S	F Z / 4 /	2724E-6A355B/G	1
205667	Kit crankshaft main bearing thrust washer .005 O/S		2724E-6A355C/H	i
205668	Kit crankshaft main bearing thrust washer .0075 0/S		2724E-6A355D/J	1
205669	Kit crankshaft main bearing thrust washer .010 0/S		2724E-6A355E/K	i
205529	Seal crankshaft front oil	F2/48	2724E-6362A	1
205671	Flywheel assembly	F2/49	2721E-6375A	1
205809	Bolt flywheel to crankshaft	F2/49 F2/50	115711-ES	6
205672	Gear flywheel ring	F2/50 F2/51	2724E-63848	1
205624	Bearing, camshaft rear - standard	F2 /52	2724E-6263C	1
2 05716 205713	Bearing, camshaft rear - 020 inch O/S	/	2724E-6263D	•
205712	Bolt connecting rod	F2/53	2724E-6215B	

F 3


Engine





PART NO.	DESCRIPTION	PLATE No.	REMARKS	QTY.
	OIL PUMP			
205673	Pump assembly, vane type		2724E-6600A	1
205674	Pump assembly, rotor type		2724E-8600A	•
	Pump body engine oil	F3/ 1	Part of 2724E-6600A	1
2057,0	Bolt pump to cylinder block, rotor type pump		111583-ES2	2
057	Bolt, pump to cylinder block		45528-ES2	1
00324	Lockwasher		34806-\$7/8	1
05783	Bolt, oil pump cover to body	F3/ 2	304848-S2	2
05810	Bolt, oil pump cover to body	F3/ 3	304794-S2	2
1 22 2 C	Washer	F3/ 4	34806-\$7/8	4
05675	Rotor, vane type pump	F3/ 5	2724E-6608A	1
05676	Rotor rotor type pump	F3/ 6	2724E-6608B	1
95677	Cover, pump rotor type	F3/ 7	2724E-6616B	1
05678	Tube, oil pump inlet assembly	F3 / 8	2724E-6617B	1
05557	Bolt, inlet tube to pump	F3/ 9	20346-\$7/8	2
1222B	Lockwasher	F3/10	34826-\$7/8	2
35679	Gasket, inlet tube	F3/11	2724E-6626A	1
35680	Shaft intermediate	F3/12	2724E-6A618A	1
05681	Ring shaft retaining	F3/13	2724E-6A707A	1
05682	Vane, oil pump rotor	F3/14	2724E-6K629A	4
05683	Spacer, oil pump rotor	F3/15	2724E-6K644A	1
35684	Seat, relief valve spring	F3/16	2724E-6653A	1
05685	Pin, relief valve spring seat	F3/17	72044-\$	1
05686	Plug, relief valve rotor pump	F3/18	2724E-6666A	1
05687	Spring, relief valve rotor pump	F3/19	2724E-6670B	1
05688	Spring, relief valve vane pump	F3/20	2724E-8670C	1
02297	Plunger, relief valve vane pump	F3/21	EOTA-6674	•
056	Plunger, relief valve rotor pump	F3/22	2724E-0674B	1






PART NO.	DESCRIPTION	PLATE NO.	REMARKS	QTY. REQ.
	MANIFOLD			
205691	Manifold, assembly inlet 3 litre	F4/, 1	2725E-9424B	- 1
205692	Manifold, assembly inlet 2.5 litre	•	2721E-9424A	1
205693	Stud, manifold to carburettor 3 litre	F4/ 2	88426-\$	2
205694	Stud, manifold to carburettor 2.5 litre		.88441-S	2
205553	Bolt, manifold to cylinder head	F4/ 3	20512-S2	4
205760	Bolt, manifold to cylinder head	F4/ 4	45512-\$2	4
200324	Washer	F4/45	34806-S	. 8
205695	Manifold, exhaust R.H	F4/56	2721E-9428A	1
205696	Manifold, exhaust L.H	F4/67	2721E-9429A	1
50062B	Bolt, manifold to cylinder head	F4/8	304720-\$7	12
205697	Washer, manifold to cylinder head	F4/ 9	112452-E8	. 12
205340	Hose, manifold to carburettor 3 litre	F4/10	2725E-9K432A	1
205698	Hose, manifold to carburettor 2.5 litre		2721E-9K432A	1
205699	Hose, carburettor to water pump 3 litre	F4/11	2725E-6K637A	1
205700	Hose, carburettor to water pump 2.5 litre		2721E-6K637A	1
205701	Clip, carburettor to pump hose to front cover		111227-ES	1
205702	Clip, carburettor hose to rocker cover bolt		112868-ES2	1
205703	Strap, carburettor hoses		E68-LD-9	1 '
205704	Spacer, carburettor to inlet manifold 3 litre	F4/12	2725E-9K437A	1
205705	Gasket, carburettor to inlet manifold 3 litre	F4/13	2725E-9K438A	1
205706	Gasket, carburettor to inlet manifold 2.5 litre		2721E-9447B	2
204714	Gasket, exhaust manifold	F4/14	2724E-9448A	6
205708	Stud, manifold to exhaust pipe	F4/15	2724E-9454A	4
205709	Gasket, inlet manifold to cylinder head 3 litre	F4/16	2721E-9A454B	1
205710	Gasket, manifold to carburetfor 3 litre	F4/17	2725E-9L553A	1
205711	Temperature transmitter	F4/18	C4AH-10884A	1

F 5


Engine





PART NO.	DESCRIPTION	PLATE NO.	REMARKS	QTY. REQ.
	GEARBOX AND ENGINE MOUNTINGS			
204590	Front support bracket engine	F5/ 1		2
50090B	Bolt, bracket to frame L.H	F5/ 2		2
5008	Bolt, bracket to frame R.H			2
5084	Nut, bracket to frame	F5/ 3		4 .
204523	Insulator, front engine support	F5/ 4		2
51483B	Bolt, insulator to support bracket	F5/ 5		4
50842B	Nut, insulator to support bracket	F5/ 6		4
50843 B	Nut. insulator to engine bracket	F5/ 7		2
204596	Engine bracket, front L.H	F5/8		1
104597	Engine bracket, front R.H			1
204598	Spacer, engine support, L.H. only	F 5/9		1
51542B	Bolt. bracket and spacer to cylinder block L.H	F5/10		2
51540B	Bolt, bracket and spacer to cylinder block R.H			2
5 1 2 0 3 B	Lockwasher, bracket and spacer to cylinder block	F5/11		4
234422	Mounting channel, gearbox	F5/12		1
5152 CB	Bolt, mounting channel to frame	F5/13		4
51203 B	Lockwasher, mounting channel to frame	F5/14		4
254524	Insulator, rear, engine support	F5/15		1
5 14 8 1 B	Bolt, insulator to mounting channel	F5/16		2
5 1 2 0 2 B	Lockwasher, insulator to mounting channel	F5/17		2
50682 B	Nut, insulator to mounting channel	F5/18		2
51540B	Bolt, insulator to gearbox	F5/19		1
5 · 203B	Lockwasher, insulator to gearbox	F5/20		1






PART No.	DESCRIPTION	PLATE NO.	REMARKS	QTY. REQ.
	GEARBOX EXTERIOR			
205742	Case, gearbox	G17 1	2802E-7008A	1
205743	Plug, filler & drain	81/2	353051-ES	2
205744	Housing, extension, assembly	G1/3	2802E-7A039A	1
205745	Vent, gearbox	G1/4	540E-4022B	1
51581B	Bolt, extension housing to gearbox	G1/5	20410-57/8	4
51224B	Lockwasher	G1/ B	34848-\$7/8	4
205746	Bearing, extension	G1/ 7	211E-7041B	1
205747	Retainer, main drive gear bearing	G1/8	2802E-7050A	1
51503B	Bolt, retainer to gearbox	G1/ 9	20366-88	4
51222B	Lockwasher	G1/10	304806-\$8	4
205748	Gasket main drive bearing retainer	G1/11	2802E-7051A	1
205749	Seal, main drive gear	G1/12	211E-7052B	1
205750	Gasket, gearbox to extension	G1/13	2802E-7086A	1
205751	Housing, clutch	G1/14	3008E-7500A	,1
50102B	Bolt, housing to cylinder block	G1/15	20448-\$7/8	6
205472	Lockwasher	G1/18	34847-ES2	6
205752	Shield, clutch release lever	G1/17	3008E-7513A	.1
205753	Pivot, clutch release lever	G1/18	3004E-7K532A	1
205754	Link, clutch release lever	G1/19	3004E-7K533A	1
205755	Bearing, clutch release pin	G1/20	3004E-7K534A	1
205756	Lever, clutch release	G1/21	3004E-7541A	1
205757	Hub, clutch release bearling	G1/22	3008E-7561A	1
205758	Spring, clutch release fork retaining	G1/23	109E-7562	1
205759	Pin, clutch release lever	G1/24	3004E-7565A	. 1
205342	Bearing, clutch release	G1/25	2400E-7580B	4
205761	Spring, clutch release bearing hub	G1/26	3004E-7605A	1
205762	Gasket, gearbox to clutch housing	G1/27	3008E-7A619A	1
205762	Seal, gearbox mainshaft	G1/28	211E-7657A	1 .
205703	Bolt, clutch housing to gearbox	G1/29	20430ES	6
51224	Lockwasher	G1/30	34848-S	6
205764	Gearhox 2 extension assembly		2802 E - 7003C	1








PART NO.	DESCRIPTION	PLATE NO.	REMARKS	QTY. REQ.
•	GEARBOX INTERIOR			
205712	Gear, main drive	G2/ 1	2802E-7017D	1
205215	Bearing, main drive gear	G2/ 2	211E-7025A	1
205714	Ring, outer main drive gear	G2/3	211E-7026	1
205715	Housing,main shaft bearing	G2/4	211E-7049B	1
10477	Pin, extension housing to mainshaft bearing retainer	G2/ 5	306305-\$	1
2 05717	Ring, third & fourth speed synchro hub	G2/6	211E-7059A	1
205718	Shaft, gearbox main	G2/ 7	2802E-7061A	1
202178	Ball, mainshaft to speedo gear	G2/8	353080-\$	i
20000	Ring inner, main drive gear	G2/ 9	211E-7064	
20 14	Bearing main shaft	G2/10	211E-7065A	1
205638	Washer thrust, gearbox mainshaft, 1st gear	G2/11	2802E-7071A	i
205722	Ring 1st & 2nd synchro hub retainer	G2/12	2802E-7K080A	1
205723	Gear 1st speed	G2/13	2802E-7100A	1
2 3 5 7 2 4	Gear, 2nd speed	G2/14	2802E-7102B	1
205725	Ring synchroniser blocking	G2/15	2802E-7107A	4
205726	Spring 3rd & 4th synchroniser	G2/16	2802E-7109A	2
205727	Spring, 1st & 2nd synchroniser	G2/17	2802E-7109B	2
205728	Countershaft	G2/18	2802E-7111A	1
205658	Washer, countershaft	G2/19	113255-ES	4
205729	Gear countershaft	G2/20	2802E-7113A	1
205730	Insert, 3rd & 4th speed synchro hub	G2/21	211E-7116	3
205731	Insert 1st & 2nd speed synchro hub	G2/22	E 4 07 - G A - 2	3
2 05664	Washer front countershaft	G2/23	2802E-7119A	1
205732	Bearing input shaft pilot	G2/24	211E-7120A	1
205733	Roller countershaft gear bearing	G2/25	211E-7121	4.4
205734	Synchroniser, 1st & 2nd gear	G2/26	2802E-7124A	1
205735	Synchroniser, 3rd & 4th gear	G2/27	2802E-7124B	1
205670	Washer rear countershaft	G2/28	211E-7128D	1
205736	Gear reverse idler	G2/29	2802E-7141A	1
205-27	Gear 3rd speed	G2/30	2802E-70340D	1
20 3	Shaft reverse gear	G2/31	211E-7140B	1





PART NO.	DESCRIPTION	PLATE No.	REMARKS	QTY. REQ.
	GEARBOX - continued		•	
205739	Gear speedo driving	G2/32	211E-17285B	1
205740	Spacer, speedo driving gear	G2/33	211E-17288B	1
205689	Nut speedo driving gear retaining	G2/34	114061-ES	1
203689	Tabwasher, speedo driving gear	G2/35	116251-ES	1
205658	Washer, countershaft	G2/36	113255-E\$	4






PART NO.	DESCRIPTION	PLATE NO.	REMARKS	QTY. REQ.
	FLOOR GEARCHANGE MECHANISM			
205765	Padestal, gearchange	. G3/1	3008E-7K137B	1
205768	Bush, pedestal	. G3/2	3008E-7K142B	1
2057	Lever, gearchange relay	. G3/3	3008E-7K138C	1
2057	Insulator, gearchange relay	. G3/4	3008E-7K094	1
205769	Clip, rod, end retaining	. G3/5	11289-ES2	1
51502B	Bolt, pedestal to extension		20346-\$7/8	2
51222B	Lockwasher		34806-S7/8	2
205613	Washer, shaft to pedestal	. G3/8	112410-ES8	1
51002B	Nut, shaft to pivot shaft finger		34443-ES7/8	1
51133B	Washer	. G3/10	44724-\$7/8	1
205811	Nut, adjuster to gate selector rod	. G3/11	33923-\$7/8	2
205770	Clip, adjuster to selector crank	. G3/12	113864-E\$32	1
205770	Clip, rod to relay lever & selector lever	. G3/13	113864-ES32	2
105771	Shaft, lever pivot	. G3/14	3008E-7K141B	1
2 05772	Adjuster, gate selector rod	G3/15	3008E-7K143B	1
205512	Washer, adjuster to crank	G3/16	356303-\$8	1
205773	Crank selector	. G3/17	3008E-7K144C	
205769	Clip, rod, end retaining	G3/18	112589-ES2	1
205775	Rod. gate selector	. G3/19	3008E-7K145B	- 1
205776	Rod, gear selector	G3/20	3008E-7K146B	1
205777	Finger, pivot shaft	G3/21	3008E-7K147B	- 1
205778	Pivot lever	G3/22	3008E-7K179A	1
205779	Fulcrum, selector crank	G3/23	3008E-7K180B	, 1
20581	Washer, fulcrum		112412-ES8	1
2057	Bush, selector crank	G3/25	3008E-7K190A	1



PART NO.	DESCRIPTION	PLATE NO.	REMARKS	QTY. REQ.
FLOOR CH	ANGE MECHANISM - continued			
205814	Bolt, lever to pivot	G3/26	112142-ES8	1
2 05815	Boot, gear lever	G3/27	3008E-7277A	1
205781	Lever, gear change R.H.D.	G3/28	3008E-7210E	1
205782	Lever, gear change L.H.D	•	3009E-7210E	1.
204832	Knob, gear lever	G3/29	3008E-7217A	1
204833	Nut, gear lever knob	G3/30	3008E-70404A	1
205784	Crank assembly, selector	G3/31	3008E-7302B	1
205795	Inculator crank	63/32	F508-GR-4	. 1

G4





PART NO.	DESCRIPTION	PLATE NO.	REMARKS	QTY. REQ.
	GEARCHANGE MECHANISM - SELECTORS			
205786	Rail, 3rd & 4th gearchange	G4/ 1	2802E-7C113A	. 1
205787	Ball, rail to gearbox	G4/ 2	353081-S	1
205788	Fork, 1st & 2nd change	G4/ 3	2802E-7C114A	1
205789	Pin, fork to rail	G4/4	305060-S	1
2057	Lever, gate to selector	G4/5	2802E-7K114A	1
5068	Nut, lever to selector arm	G4/6	33798-\$7/8	i
205798	Washer tab	G4/ 7	E519-GB-7	1
205791	Shaft, gearchange	G4/8	2802E-7K122B	1
205848	Washer, shaft to housing	G4/ 9	116229-ES	1
205792	Seal shaft	G4/10	E169-GB-7	1
205793	Washer, seal	.,	E244-GB-7	1
205794	Ring, shaft	G4/11	E229-GB-7	1
205795	Arm & Shaft assembly	G4/12	2802E -7K125A	1
205796	Gate, 1st & 2 nd	G4/13	2802E-7K130A	1
205797	Gate. 3rd & 4th	G4/14	2802E-7K131A	1
205789	Pin, gate to rail	G4/15	305060-S	2
205799	Plunger, rail interlock	G4/16	2802E-7K132A	2
205800	Housing selector assembly	G4/17	2802E-7201	1
205801	Housing	G4/18	2802E-7222B	1
202156	Plug. housing	G4/19	115419-ES	1
205802	Bolt. selector housing to gearbox	G4/20	20346-\$2	3
205825	Bolt, selector housing to gearbox	G4/21	20408-\$2	1
205827	Lockwasher	G4/22	34806-\$2	. 4
205803	Gasket	G4/23	2802E-7223A	1
205804	Lever, raverse	G4/24	2802E-7C312A	1
20580	Spring, reverse, stop	G4/25	E224-GB-7	1
2058	Seat outer, reverse stop spring	G4/28	E171-GB-7	1
205807	Ring, reverse, stop	G4/27	E178-GB-7	2




PART NO.	DESCRIPTION	PLATE NO.	REMARKS	QTY. REQ.
SELECTORS	- continued			
•				
205818	Lever, gearchange	G4/28	2802E-7439B	1
205848	Nut	64/29	34445-ES2B	1
205847	Washer	G4/30	44727-S2	1
205819	Fork, 3rd & 4th	G4/31	2802E-7230A	1
205820	Fork, reverse		2802E-7231A	1
205821	_ Spring, mesh lock	G4/33	204E-7234	3
205822	Pin, rail interlock	G4/34	105E-7235	1
205823	Rail, 1st & 2nd		2802E-7240A	1
205824	Rail, reverse	G4/38	2802E-7242A	1
205787	Ball, rail to gearbox		353081-8	2
205826	Arm, gearchange	G4/37	2802E-7243A	1
205789	Pin, fork	G4/38	305060-S	2
205832	Pin, housing to gearbox	G4/39	73229-\$2	2
205828	Lever, overdrive control	64/40	2802E-6939-A	1
205829	Seal, shaft	G4/41	109E-7288	. 2

•




Clutch





PART NO.	DESCRIPTION	PLATE NO.	REMARKS	QTY. REQ.
	CLUTCH			
205751	Housing, clutch	H1/ 1	3008E-7500A	1,55
50102B	Bolt, housing to block	H1/ 2	20448-\$7/8	R A
205472	Lockwasher	H1/ 3	34847-ES2	F F
205831	Shield, clutch release lever	H1/ 4	3008E-7513	1
205753	Pivot	H1/ 5	3004E-7K532A	i
2057	Link	H1/6	3004E-7K533A	1
20575	Bearing	H1/ 7	3004E-7K534A	1
205756	Lever, release	H1/8	3004E-7541A	1
205836	Disc assembly	H1/ 9	2721E-7550B	- 1
205757	Hub, release bearing	H1/10	3008E-7561A	1
205758	Spring, release fork retaining	·H1/11	109E-7562	1
205839	Plate, pressure	H1/12	2721E-7563B	1
205759	Pin. release lever	H1/13	3004E-7565A	1
205841	Bearing, clutch release	H1/14	2400E-7580A	1
205842	Bearing assembly		2720E-7600B	1
205761	Spring	H1/15	3004E-7605A	1
205752	Gasket, housing to gearbox	H1/16	3008E-7A619A	1
205845	Gasket, main drive bearing retaining	H1/17	2802E-7051	1
51224B	Washer, housing to gearbox	H1/18	34848-\$7/8	4
205830	Bolt, housing to gearbox	H1/19	2039σ-ES	4
200324	Washer, hub to housing	H1/20	34806-58	4
51503	Bolt, hub to housing	H1/21	20366-\$	4 -
205747	Retainer, main drive gear bearing	H1/22	2802E-7050A	1 .






PART NO.	DESCRIPTION	PLATE NO.	REMARKS	QTY. REQ.
	HYDRAULICS AND MASTER CYLINDER			
200981	Master cylinder	H2/ 1		1
	Body	H2/ 2	Not available	,
17809	Filler cap	H2/3	***************************************	i
17808	Gasket, filler cap	H2/4	• • • • • • • • • • • • • • • • • • • •	;
201342	Seal, valve	H2/ 5		1
201343	Stem, valve	H2/6	• • • • • • • • • • • • • • • • • • • •	;
201345	Spring, washer	H2/ 7		
201344	Spacer, valve	H2/ 8		,
201305	Spring, push rod return	H2/ 9	••••••	1
201348	Retainer, spring	H2/10	••••••	
201341	Seal, plunger	H2/11	• • • • • • • • • • • • • • • • • • • •	1
201431	Plunger	H2/12	• • • • • • • • • • • • • • • • • • • •	,
7677	Retaining washer	H2/13		
7673	Circlip	H2/14	*****************	1
17807	Push rod	H2/15	• • • • • • • • • • • • • • • • • • • •	1
4215	Locknut	H2/16	•••••••	,
4180	Clevis	H2/17	••••••••••••	. 1
4181	Nu t	H2/18	•••••••••••	
201335	Dust cover	H2/10	•••••••	
205158	Crimping sleeve, dust cover	H2/10	• • • • • • • • • • • • • • • • • • • •	
201336	Retaining band, dust cover	H2/21	• • • • • • • • • • • • • • • • • • • •	
17908	Service Kit	NZ/Z1	• • • • • • • • • • • • • • • • • • • •	,
200570	Bundy tube, master cylinder to flexible hose	H2/22		,
8896	Flexible hose	H2/22	• • • • • • • • • • • • • • • • • • • •	•
3934	Nut, bundy tube to flexible hose	H2/24	••••••	
3932	Gasket, bundy tube to flexible hose	H2/25	••••••	•
3933	Lockwasher	H2/25	• • • • • • • • • • • • • • • • • • • •	· ;
200554	Banjo	H2/20		
200555	Bolt, banjo	H2/27	• • • • • • • • • • • • • • • • • • • •	
200556	Gasket, banjo	H2/20	**************	•
205952	Slave cylinder assembly	H2/29	3004E-7A508-A	2
10563	Dust cover	H2/30	E91-GD-2	•
205954	Retaining ring *	H2/31		
205955	Bleed screw, slave cylinder		E115-GD-2	1
205956	Dust cap, bleed screw	H2/33	100E-2208	
07870	DUST CAD, DIBEC SCIEW	H2/34	F04-2200	1

H 3

Clutch





			A STATE OF THE STA			
PAR	DESCRIPTION	PLATE NO.	REMARKS	QTY. REQ.		
	ACCELERATOR, BRAKE AND CLUTCH PEDALS					
204628	Mounting bracket, pedals	H3/ 1		1		
5 483B	Bolt, mounting bracket to body	H3/ 2		4		
511328	Washer, mounting bracket to body	H3/ 3		Ā.		
51092B	Nut, mounting bracket to body	H3/4		4		
50042B	Bolt, master cylinder to bracket	H3/5		4		
C#300	Washer, master cylinder to bracket	H3/6		4		
51 C C 2 B	Nut, master cylinder to bracket	H3/ 7		Ā		
205295	Pedal and lever assembly, clutch	H3/8		1		
205297	Pedal and lever assembly, brake	H3/ 9		i		
200279	Pedal, brake	H3/10		i		
204742	Pedal, clutch	H3/11	Early R.H.D.	i		
200273	Lever, brake and clutch	H3/12	3 litre only	2		
50706 B	Locknut, pedal to lever	H3/13	•,	4		
3151	Cover, pedal pad	H3/14		2		
200276	Bush, pedal lever pivot	H3/15		2		
50049B	Bolt, pedal lever pivot	H3/16		2		
511228	Washer, pivot bolt	H3/17		2		
510	Nut, pivot bolt	H3/18		2		
2054	Spring, lever return	H3/19		2		



Clutch


|--|

PART NO.	DESCRIPTION	PLATE No.	REMARKS	QTY. REQ.
	PEDAL ASSEMBLY - continued			
200704	Clevis pin, brake lever to master cylinder	H3/20		1
3150	Clevis pin, clutch lever to master cylinder	H3/21		1
51122B	Washer, clevis pin	H3/22	•••••	2
53846B	Split pin, clevis pin	H3/23 .		2
50007B	Bolt, clutch lever stop	H3/24	• • • • • • • • • • • • • • • • • • • •	1
50703B	Locknut, clutch lever stop		• • • • • • • • • • • • • • • • • • • •	1
204875	Accelerator pedal assembly	H3/26	••••••	1
200278	Bush, pedal pivot			i
50049B	Bolt, pedal pivot			i
51002B	Nut, pedal pivot		••••••	1
204707	Bell crank		• • • • • • • • • • • • • • • • • • • •	i
204741	Bush, bell crank	H3/31		i
50045B	Bolt, bell crank			1
51002B	Nut, bell crank	H3/33		•
204698	Link, throttle			2
54817B	Clevis pin, throttle link			2
51121B	Washer, throttle link			4
53810B	Split pin, throttle link			2
204704	Cable, accelerator			1
204699	Cable pin c.w. bolt			,
204747	Washer			2
51448B	Screw, accelerator stop			- 1
53703B	Locknut, accelerator stop			1
1.7814	Spring, accelerator pedal return			1
17302			• • • • • • • • • • • • • • • • • • • •	1
17302	Switch, brake light			<u>'</u>
1/381	Locknut, brake light switch	H3/45		2

J 1

Propeller Shaft






PART NO.	DESCRIPTION	PLATE NO.	REMARKS	QTY. REQ.
	PROPSHAFT	. *		•
204405	Propshaft assembly	•		1
205466	Flange yoke	. J1/ 1-		1
205468	Unit package (Journal Kit)	. J1/2		2
205470	Circlip	. J1/3		8
205469	Lip seal	. J1/4		8
205467	Sleeve yoke	. J1/5		1
205471	End plug	. J1/8		1
50081B	Bolt, propshaft fixing	. J1/7	• • • • • • • • • • • • • • • • •	4
50843B	Nut. propshaft fixing	. J1/8·		4







PART NO.	DESCRIPTION	PLATE NO.	REMARKS	QTY. REQ.
	ŘEAR AXLE			•
204417	Axle assembly c.w. brakes, hubs and drums, 3.58:1		Standard	1
204418	Axle assembly less brakes, hubs and drums, 3.58:1		Standard	. 1
204618	Axle assembly c.w. brakes, hubs and drums, 3.73:1		Optional	1
205087	Axie assembly less brakes, hubs and drums, 3.73:1		Optional	1
204619	Axle assembly c.w. brakes, hubs and drums, 3.91:1		Optional	1
205088	Axle assembly less brakes, hubs and drums, 3.91:1		Optional	1
204613	Axle assembly c.w. brakes, hubs and drums, 4.10:1		Optional	1
205089	Axle assembly less brakes, hubs and drums, 4.10:1		Optional	1
204612	Axle assembly c.w. brakes, hubs and drums, 4.56:1		Optional	1
205090	Axle assembly less brakes, hubs and drums, 4.56:1		Optional	1
205092	Axle case and tube assembly	K1/ 1		1
202434	Drain plug	K1/ 2		1
202465	Nut, pinion	K1/3		1
202466	Washer, pinion	K1/4	• • • • • • • • • • • • • • • • • • • •	1
202464	Flange, pinion	K1/5		1
202463	Seal, pinion	K1/ 6		1
202462	Oil slinger, pinion	K1/7		5.1
202454	Pinion bearing, tai [®] l	K1/8		***1




Rear Axle



PAR NO.	DESCRIPTION	PLATE No.	REMARKS	QTY. REQ.
	REAR AXLE - continued		•	
02455	Shim, pinion bearing, inner003	K1/ 9	• • • • • • • • • • • • • • • • • • • •	. As req*d
02456	Shim, pinion bearing, inner005		• • • • • • • • • • • • • • • • • • • •	. As reg*d
02457	Shim, pinion bearing, inner010		• • • • • • • • • • • • • • • • • • • •	. As req*d
02458	Shim, pinion bearing, outer003	K1/10	•••••	As req'd
02459	Shim, pinion bearing, outer005		• • • • • • • • • • • • • • •	. As req'd
02460	Shim, pinion bearing, outer010		· · · · · · · · · · · · · · · · · · ·	. As reg*d
02461	Shim, pinion bearing, outer030		• • • • • • • • • • • • • • • • • • • •	As reged
02453	Pinion bearing, head	K1/11	• • • • • • • • • • • • • • • • • • • •	=
02439	Differential case assembly (for all ratios except		• • • • • • • • • • • • • • • • • • • •	
05093	4.58:1) Differential case assembly (for ratio 4.58:1 only)		• • • • • • • • • • • • • • •	. 1
02440	Differential case (for all ratios except 4.58:1).	K1/12		. 1
05094	Differential case (for ratio 4.58:1 only)			. 1
02427	Crown wheel and pinion 3.58:1	K1/13	Standard	. 1
02486	Crown wheel and pinion 3.73:1		Optional	
02487	Crown wheel and pinion 3.91:1		Optional	. 1
02488	Crown wheel and pinion 4.10:1		Optional	
02488	Crown wheel and pinion 4.58:1		Optional	. 1
024	Bolt, crown wheel to differential case	K1/14		. 8
0244	Differential bearing	K1/15	• • • • • • • • • • • • • • • • • • • •	. 2
02449	Shim, bearing003	K1/16	• • • • • • • • • • • • • • • • • • • •	. As req*d
02,435	Cap, bearing	K1/17	• • • • • • • • • • • • • • • • • • • •	. 2
02436	Screw, cap	K1/18	• • • • • • • • • • • • • • • • • • • •	. 4
02437	Lockwasher, cap	K1/19		. 4
04042	Cover, gear carrier	K1/20		. 1
02431	Gasket, cover	K1/21		. 1
0079B	Bolt, cover to gear carrier	K1/22		10
1202B	Lockwasher, cover to gear carrier	K1/23		. 10
04119	Filler plug, cover	K1/24	• • • • • • • • • • • • • • • • • • • •	. 1
02445	Differential pin	K1/25	• • • • • • • • • • • • • • • • • • • •	. 1
02446	Locking pin, differential pin	K1/28		. 1
02443	Differential pinion	K1/27		. 2
02444	Thrust washer, differential pinion	K1/28		. 2
02441	Differential side gear	K1/29		
02442	Thrust washer, side gear	K1/30		_
05091	Axle shaft, 27 00 inches long	K1/31		_
03091	Key, axle shaft	K1/32		_
02478	Cotter pin, axle shaft	K1/33		
02468	Bearing, axle shaft	K1/34		_
02400	Washer, axie shaft	K1/35		2
0247	Nut, axle shaft	K1/38		. 2
02475	Grease nipple	K1/37		
02469	Shim, axle shaft bearing003	K1/38		
02 4 7 Ó	Shim, axle shaft bearing005	K1700		
02470	Shim, axle shaft bearing010			
0247:	Shim, axle shaft bearing030			
02474	Oil seal, inner	K1/39		_
	Plate, axle shaft bearing retaining	K1/39		_
02473				-
02480	Oil seal assembly, hub	K1/41		
02481	Oil seal	K1/42		_
	Container, oil seal	K1/43	***********	
22482	Gasket, oil seal container to backplate	K1/44		
02483 02485	Bolt, brake back plate to axle	K1/45	· · · · · · · · · · · · · · · · · · ·	
	Washer, brake back plate to axle	K1/48		
C2 4 84	Nut brake back plate to axle	K1/47	• • • • • • • • • • • • • • • •	
01213	Rear hub assembly c.w. studs	K1/48		
00255	Stud, rear hub	K1/49		. 8






PART NO.	DESCRIPTION	PLATE NO.	REMARKS	QTY. REQ.
	FRONT CALIPER AND DISC Type 17/3			
205137	Front caliper assembly L.H			1
205138	Front caliper assembly R.H.			,
205228	Pad assembly	L1/ 1		
201134	Pin, pad retaining	L1/ 2		7
201135	Clip, pad retaining	L1/ 3		7
205088	Piston, inner	L1/ 4	**************	,
205233	Piston, outer	L1/ 5		4
17804	Bleed screw	L1/ B		2
17799	Dust cap	L1/ 7		2
205235	Service Kit, caliper	- · ·		-
205230	Rubber boot (inner)	L1/8		2
205231	Rùbber boot (outer)	L1/ 9		2
205229	Sealing ring (inner)	L1/10		. 2
205232	Sealing ring (outer)	L1/11		4
203487	Bolt, caliper mounting	L1/12		2
204204	Bolt, caliper and brake pipe mounting	L1/13		2
51203B	Lockwasher, caliper mounting	L1/14		4
204205	Anchor bracket, brake pipe	L1/15		2
508825	Locknut	L1/16		2
203361	Disc assembly	L1/17		2
50083B	Bolt, disc to hub	L1/18		8
51203B	Washer, disc to hub	L1/19		8
203391	Dust cover assembly L.H	•		. 1
203390	Dust cover assembly R.H	L1/20		1
51520B	Set screw, cover to vertical link	L1/21		2
51203	Lockwasher, cover to vertical link	L1/22	• • • • • • • • • • • • • • • • • • • •	2


L 2






PART NO.	DESCRIPTION	PLATE NO.	REMARKS	QTY.
	REAR BRAKE DRUM AND BACKPLATE			
204112	Rear brake assembly L.H	·	••	
204113	Rear brake assembly R.H		••••••	- 1
201104	Backplate L.H.		••••••	}
201105	Backplate R.H.	L2/1	• • • • • • • • • • • • • • • • • • • •	1
201107	Lined shoe, feading	L2/ 1 L2/ 2	••••••	1
201106	Lined shoe, trailing	L2/ 2 L2/ 3	• • • • • • • • • • • • • • • • • • • •	2
201112	Spring, cylinder end		• • • • • • • • • • • • • • • • • • • •	2
201113	Spring, adjuster end	L2/4	• • • • • • • • • • • • • • • • • • • •	2
201	Wheel cylinder assembly	L2/5	••••••	2
17900	Bleed screw	L2/6	**************	2
17799	Dust cap	L2/ 7		2
201117	Lever	L2/ 8 L2/ 9	• • • • • • • • • • • • • • • • • • • •	2
201118	Dust cover	L2/.9 L2/10	• • • • • • • • • • • • • • • • • • • •	2
221114	Retaining plate	L2/10 L2/11	• • • • • • • • • • • • • • • • • • • •	2
201115	Spring plate	L2/11 L2/12	••••••	. 2
221118	Distance washer		• • • • • • • • • • • • • • • • • • • •	2
201300	Adjuster	L2/13 L2/14	• • • • • • • • • • • • • • • • • • • •	2
7722	Washer, adjuster fixing	L2/14 L2/15	• • • • • • • • • • • • • • • • • • • •	2
7723	Nut. adjuster fixing	L2/15 L2/16		4
221298	Service Kit, steady post	L2/16	• • • • • • • • • • • • • • • • • • • •	. 4
	Steady post	L2/17	• • • • • • • • • • • • • • • • • • • •	2
	Clip	L2/17 L2/18	••••••	2
201850	Service Kit, wheel cylinder	L2/18	• • • • • • • • • • • • • • • • • • • •	2
	Dust cover	L2/19	• • • • • • • • • • • • • • • • • • • •	2
	Clip, dust cover	L2/19 L2/20	• • • • • • • • • • • • • • • • • • • •	2
	Seal	L2/20	••••••	2
	Dust cap	, - .	• • • • • • • • • • • • • • • • • • • •	2
201301	Service Kit, adjuster	L2/ 8	• • • • • • • • • • • • • • • • • • • •	2
	Link	12/00	•••••	2
	Wedge	L2/22	• • • • • • • • • • • • • • • • • • • •	4
2001	Orum, rear brake	L2/23	• • • • • • • • • • • • • • • • • • • •	2
517290	Screw drum to bub	L2/24	• • • • • • • • • • • • • • • • • • • •	2
2.200	Screw, drum to hub	L2/25		4





PART NO.	DESCRIPTION	PLATE NO.	REMARKS	QTY. REQ.
	HANDBRAKE	1	·	Section 1
201624	Handbrake lever	L3/ 1		
201820	Handgrip	L3/ 1	• • • • • • • • • • • • • • • • • • • •	•
50442B	Bolt, handbrake lever to chassis	L3/ 2	• • • • • • • • • • • • • • • • • • • •	• • • •
200252	Spacer, handbrake lever to chassis	L3/ 3	• • • • • • • • • • • • •	
50882B	Nut, handbrake lever to chassis			
51122B	Washer, handbrake lever to chassis	. L3/5 L3/6	•••••••••	
204098	Cable handbrake		• • • • • • • • • • • • • • • • • • • •	
204087	Clevis and screw assembly	L3/7	* *************************************	
50704B	Locknut	L3/8	•••••••	-
204082	Eye bolt	L3/ 9	• • • • • • • • • • • • • • • • • • • •	
204083	Adjusting nut	L3/10	• • • • • • • • • • • • • • • • • • • •	• • •
204085	Compensating multiple	L3/11	• • • • • • • • • • • •	
54843	Compensating pulley	L3/12	• • • • • • • • • • • • • • • • • • • •	
53846B	Clevis pin, handbrake lever and pulley	L3/13	• • • • • • • • • • • • • • • • • • • •	· · · · · · · · · · · · · · · · · · ·
51122B	Split pin	L3/14	••••••••••	
204120	Plain washer	L3/15		2
511418	Clip, cable to axle	L3/16	••••••	
	Set screw, clip securing	L3/17	• • • • • • • • • • • • • • • • • • • •	🥕 2
50961B	Nut, clip securing	L3/18	• • • • • • • • • • • • • • • • • • • •	2
200413	Clip, L.H. to R.H. cable	L3/19		2
3150	Clevis pin, clevis to lever	L3/20		2
53846B	Split pin, clevis to lever	L3/21		2
51122B	Washer, clevis to lever	L3/22	• • • • • • • • • • • • • • • • • • • •	2
204605	Abutment bracket R.H	L3/23		1
204606	Abutment bracket L.H		* * * * * * * * * * * * * * * * * * * *	1
204115	Abutment bracket R.H	L3/24	Early vehicle	
204114	Abutment bracket L.H	, - '	only	· ;






PART NO.	DESCRIPTION	PLATE NO.	REMARKS	QTY REQ
	HYDRAULICS			
203956	Master cylinder			1
205145	Body	L4/ 1		1
201310	Filler cap	L4/ 2		1
17793	Gasket	L4/ 3	• • • • • • • • • • • • • • • •	1
201342	Seal, valve	L4/ 4		1
201343	Stem, valve	L4/ 5		1
201345	Spring washer	L4/ 6		1
201344	Spacer	L4/ 7		1
201305	Spring, push rod return	L4/8	• • • • • • • • • • • • • • • • • • • •	1
201346	Retainer, spring	L4/ 9		1
20006	Plunger	. L4/10		1
205147	Seal, plunger	L4/11		1
7669	Push rod	L4/12		1
205149	Retaining washer	L4/13		1
205148	Circlip	L4/14		1
205150	Dust cover	L4/15		1
4215	Locknut	L4/16		1
205151	Clevis	L4/17		1
17812	Service Kit for master cylinder			
, , ,	Seal, valve	L4/_4		1
	Spring washer	L4/ 6		1
	Seal, plunger	L4/11		1
	Circlip	L4/14		1
	Dust cover	L4/15		1
203830	Vacuum servo	L4/18		1
204657	Mounting bracket, servo	L4/19	R.H.D. only	1
204936	Mounting bracket, servo		L.H.D. only	1
51522B	Set screw, servo mounting bracket	L4/20		7
51123B	Washer, servo mounting bracket	L4/21		7
51003B	Nut, servo mounting bracket	L4/22		4
7443	Bundy tube, servo to master cylinder	L4/23	R.H.D. only	1
BEE 1	Bundy tube, servo to master cylinder		L.H.D. only	1
20 2	Banio complete with non-return valve	L4/24		1



PART NO.	DESCRIPTION	PLATE NO.	REMARKS	QTY. REQ.
	HYDRAULICS AND MASTER CYLINDER - continued			
203834	Gasket, banjo	L4/25		2
203833	Bolt, banjo fixing			1
205157	Vacuum hose		R.H.D. only	i
205178	Vacuum hose	.,	L.H.D. only	1.
204688	Adaptor, vacuum hose to windscreen washer		***************************************	1
204687	Adaptor, vacuum hose to cylinder block		************	i
54761B	Clip, vacuum hose		*****************	,
8798	Bundy tube, servo to 3-way	L4/31	R.H.D. only	ī
200468	Grommet, servo to 3-way bundy tube		R.H.D. only	1
204653	Bundy tube, servo to union		L.H.D. only :	1.
7438	Union		L.H.D. only	i
200570	Bundy tube, union to 3-way		L.H.D. only	i
7439	3-way	L4/33		2
202597	Restrictor valve	-4,00	Early vehicles only	_
50003B	Bolt, 3-way to frame			2
51001B	Nut, 3-way to frame			2
204650	Bundy tube, 3-way to 3-way			1
204653	Bundy tube, 3-way to L.H. hose			
200569	Bundy tube, 3-way to R.H. hose			
204654	Hose, front, L.H. and R.H.			,
3934	Bulkhead nut brake hose			6
3933	Lockwasher, brake hose		•	0
201814	Bundy tube, front brake hose to caliper		• • • • • • • • • • • • • • • • • • • •	0
8799 .	Bundy tube, 3-way to rear brake hose		• • • • • • • • • • • • • • • • • • • •	2
17843			• • • • • • • • • • • • • • • • •	!
	Rear brake hose	L4/44	• • • • • • • • • • • • • • • • • • • •	1
204652	Bundy tube, rear hose to R.H. brake		• • • • • • • • • • • • • • • • • • • •	1
6609	Bundy tube, R.H. brake to L.H. brake		• • • • • • • • • • • • • • • • • • • •	1
5496	Clip, rear brake pipe		• • • • • • • • • • • • • • • • • • • •	2
3545	Clip, brake pipes	L4/48		9





PART NO.	DESCRIPTION	PLATE NO.	REMARKS	QTY. REQ.
	SERVO			•
203830	Servo assembly			1
206251	Body, valve	L5/ 1		1
206252	Element	L5/ 2		1
008253	Cover element	L5/ 3		1
06254	Gasket	L5/ 4		1
06255	Screw	L5/ 5		1
008258	Valve assembly	L5/ 6		1
108257	Retainer, valve	L5/ 7		1
06258	Spring, valve retainer	L5/ 8		1
05259	Screw valve retainer to body	L5/ 9		1
006260	Control piston	L5/10		1
06261	Seal, secondary	L5/11		ĺ
05252	Seal, primary	L5/12		1
06263	Abutment	L5/13		1
05254	Spring	L5/14		1
05265	Retainer, spring	L5/15		1
05265	Circlip	L5/16		1
06287	Plug	L5/17		. 1
08268	Taper seal			1
05759	Spring, piston	L5/19		1
06270	Output piston assembly	L5/20		1
205271	Seal piston			1



PART NO.	DESCRIPTION	PLATE NO.	REMARKS	Q T Y R E Q
	SERVO UNIT - continued			
206212	Washer	L5/21		1
206273	Circlip	L5/22		1
206274	Spacer	L5/23		1
206275	Seal	L5/24		1
206276	Bush	L5/25		1
206277	Vacuum cylinder	L5/26		1
2 062 7 8	Clamping plate	L5/27		1
206279	Gasket, clamping plate	L5/28		1
206280	Screw, clamping plate	L5/29		3
206281	Washer, clamping plate	L5/30		1
206282	Spring, vacuum piston	L5/31		1
206283	Vacuum piston assembly	L5/32		1
206284	Gasket, piston assembily	L5/33		1
206285	Cover	L5/34		1
2.06286	Set screw, cover to cylinder	L5/35		7
206287	Nut, cover to cylinder	L5/36		7
206288	Vacuum pipe assembly	L5/37		1
206289	Rubber grommet, pipe	L5/38		1
206290	Retaining plate, pipe	L5/39	• • • • • • • • • • • • • • •	1
206291	Gasket, pipe mounting	L5/40	• • • • • • • • • • • • • • • • • • • •	1
206292	Set screw, pipe mounting	L5/41	• • • • • • • • • • • • • • • • • • • •	3
206293	Washer, pipe mounting	L5/42		3
206294	Service kit, servo			1
206261	Seal, secondary, control piston	L5/11		1
206262	Seal, primary, control piston	L5/12		1
206268	Taper seal, control piston	L5/18		. 1
208270	Output piston assembly	L5/20		1
206273	Circlip	L5/22		1
206275	Seal	L5/24		,1
206279	Gasket, clamping plate	L5/28	• • • • • • • • • • • • • • • • • • • •	1
206280	Gasket, cover	L5/29		1
206289	Rubber grommet, vacuum pipe	L5/38		1
2 06 2 9 0	Gasket, pipe mounting	L5/39		:



Road Wheels




PART NO.	DESCRIPTION	PLATE NO.	REMARKS .	QTY. REQ.
•	ROAD WHEELS			
204560	Wheel			
201189	Inner tube	t ed	••••••	5
2 13 03 5	Tyre	, E	• • • • • • • • • • • • • • • • • • • •	5
200254			• • • • • • • • • • • • • • • • • • • •	5
	Nut, wheel fixing	S	• • • • • • • • • • • • • • • • • • • •	16
204807	Nave plate	2	• • • • • • • • • • • • • • • • • • • •	4
2 0 4 8 0 6	Trim, wheel		•	7
9787	Retainer, spare wheel		• • • • • • • • • • • • • • • • • • • •	•
6391	Nut appro wheel arts!	. ¥	• • • • • • • • • • • • • • • • • • • •	1
0391	Nut, spare wheel retaining	ž	• • • • • • • • • • • • • • • • • • • •	1



Exhaust System






PART No.	DESCRIPTION	PLATE NO.	REMARKS	QTY. REQ.
	EXHAUST SYSTEM		· .	
204611	Down pipe, exhaust	NT/ 1	· · · · · · · · · · · · · · · · · · ·	•
204627	Clamp, down pipe to manifold	N1/ 2	• • • • • • • • • • • • • • • • • • • •	2
50751L	Nut, clamp to manifold	N1/ 3	• • • • • • • • • • • • • • • • • • • •	4
204425	Silencer R.H.			- 1
204934	Silencer L.H		·	•
204498	Clamp, silencer to downpipe and tail pipe		• • • • • • • • • • • • • • • • • • • •	
205193	Tail pipe R.H.	M1/ 3	• • • • • • • • • • • • • • • • • • • •	4
205192	Tail pipe L.H.		• • • • • • • • • • • • • • • • • • • •	
204352	Angle bracket, tail pipe front to support strap	N1/ 0	••••••	:
204540	Strap, exhaust support, front	N1/7	• • • • • • • • • • • • • • • • • • • •	
51483B	Set screw, front support fixing	N1/8	• • • • • • • • • • • • • • • • • • • •	2
7917	Rectangular washer for set screw	N1/9	• • • • • • • • • • • • • • • • • • • •	4
51002B	Nut for set screw	N1/10	• • • • • • • • • • • • • • • • • • • •	4
204540	Strap, exhaust support, rear	N1/11	• • • • • • • • • • • • • • • • • • • •	2
51483B	Set screw, rear support strap fixing		••••••	2
7917			• • • • • • • • • • • • • • • • • • • •	4
51 002 B	Rectangular washer for set screw		• • • • • • • • • • • • • • • • • • • •	4
J 1 UUZ D	Nust for set screw	N1/15		4













PART NO.	DESCRIPTION	PLATE NO.	REMARKS	QTY. REQ.
CARBURETTO	R 3 litre - continued			
205907	Chamber assembly	P1/60	2725E-9K732A	1
205908	Bolt, chamber	P1/81	111646-ES7	1
205909	Washer	P1/62	112515-ES	1
205910	Gasket, chamber to thermostat	P1/63	2725E-9K733A	1
205911	Screw, fast idler lever pivot	P1/64	2725E-9K735A	1
205912	Washer, fast idler lever pivot	P1/65	112516-ES	1
205913	Rod, choke operating	P1/68	2725E-9K738A	1
205914	Pin, split, rod	P1/67	119724-ES2	2
205915	Lever assembly, choke	P1/68	2725E-9K737A	1
205916	Nut, choke lever	P1/69	114477-ES7	1
205917	Washer	P1/70	112511-ES7	1
205918	Ring, locking	· P1/71	2725E-9K738A	1
205919	Screw, choke plate	P1/72	2725E-9A767A	4
205920	Lever, fast idling adjusting	P1/73	2725E-9B792A	1
205921	Spring, throttle control return R.H	P1/74	2725E-9B848A	1
205922	Spring, throttle control return L.H.	P1/75	2725E-9B848B	1
205	Valve, accelerator pump discharge	P1/78	2725E-9902A	1
2059	Spring, economy valve diaphragm	P1/77	2725E-9907A	1
205925	Gasket, nozzle bar	P1/78	2725E-9926A	1
205926	Nozzle, No.50	P1/79	2725E-9940A	1
205927	Jet, starting	P1/80	2725E-9971A	2
205928	Nut	P1/81	114212-ES	1
205929	Washer, screw, cover fixing	P1/82	112511-ES	1
205930	Gasket, choke body		2725E-9K729A	1














PART NO.	DESCRIPTION	PLATE NO.	REMARKS	QTY. REQ.
	CARBURETTOR 2.5 litre			
206009	Carburettor assembly		2721E-9510B	1
206041	Washer, choke body seal	P2/ 1	112504-ES	i
206042	Plate, throttle stop	P2/ 2	2724E-9L520B	-1
206043	Clip, accelerator shaft retaining	P2/3	372999-\$2	1
206044 206045	Lockwasher, accelerator to pump operating	P2/ 4	118088-ES	1
208045	Washer, pump link pin	P2/5 P2/6	112443-ES7	2
208047	Screw, horn to main body	P2/ 0 P2/ 7	2724E-9524B 111549-ES7	1 2
206048	Jet, compensating well	P2/ 8	E810-CL-7	. 2
206049	Link, mecelerator pump	P2/ 9	2724E-9L525B	1
206050	Pin, link to throttle stop lever	P2/10	996458-ES6	1
206051	Pin, pump link	P2/11	E301-CL-2	1
206052	Pin, cotter, link pin	P2/12	72000-\$	1
206053 206054	Jet, main metering No.102	P2/13	2724E-9533A	1
200054	Jet, fuel compensating No.120	P2/14 P2/15	2724E-9534A 2724E-9E536B	1
20008	Washer, fast idle link to fast idle lever	P2/16	118130-ES	;
208057	Washer, fast idle lever pivot post	P2/17	112509-ES	i
208058	Needle, idle adjusting	P2/18	2724E-9541A	1
206059	Washer, choke shaft	P2/19	113204-ES	. 1
208060	Lever, choke		2724E-9D542B	1
206061	Piston assembly	P2/21	2724E-9B544A	1
206062 206063	Jet, idling No.55	P2/22	400E-9545	1
208063	Shaft, choke assembly	P2/23 P2/24	2724E-9546B	1
208065	Plate, choke	P2/24 P2/25	996302-ES7 2724E-9549A	1
206086	Screw, plate to spindle	P2/26	111551-ES7	2
208087	Float and lever assembly	P2/27	2724E-9550A	-1
206068	Valve, assembly	P2/28	2724E-9584A	1
208069	Retainer, valve	P2/29	2724E-9575A	1
206070	Ball, pump check	P2/30	2724E-9576A	1
206071	Spring, idle adjusting needle	P2/31	N-9578	1
206072	Shaft, throttle	P2/32	2721E-9582A	1
208073 208074	Washer	P2/33 P2/34	112503 ES7	1
206074	Plate, throttle	P2/34 P2/35	2724E-9583A 2721E-9585A	1
206076	Screw, plate fixing	.P2/38	2721E-99684A	2
205037	Tube, horn ventilation	P2/37	2724E-9A597A	1
206	Rod, fast idle	P2/38	2724E-9598	1
208079	Pin, cotter, fast idle rod	P2/39	119703-ES	2
206080	Nut, pump lever shaft	P2/40	400E-9878	. i .
206081	Lockwasher, throttle lever to shaft	P2/41	116066-ES	1
206082 206083	Screw, throttle adjusting	P2/42 P2/43	YE-9681 YE-9682	1
206084	Screw, economiser to bowl horn	P2/43 P2/44	YE-9687A	3
206086	Lockwasher, choke body to hown screw	P2/46	34843-S	3
206087	Screw, thermostat to choke body	P2/47	N-9690	3
206088	Block, assembly	P2/48	2721E-9693A	1
206089	Screw, horn to body	P2/49	996019-ES7	2
206090	Screw, block to horn	P2/50	111550-ES7	2
205087	Lockwasher	P2/51	34843-\$	2
206091	Ring, emulsion block to main body venture	P2/52	116603-ES,	1
206092	Nut. choke lever	P2/53	2724E-9K726A	1
206 09 3 205094	Washer, water chamber bolt	P2/54 P2/55	111616-ES 112505-ES	1
205094	Gasket, water chamber to thermostat	P2/55 P2/56	2724E-9K733A	1
205095	Spring, choke	P2/57	2724E-9K734A	· i
206097	Screw, fast idler lever pivot	P2/58	2724E-9K735A	1
205098	Washer	P2/59	118134-ES7	1
2 06 246	Valve, pump discharge	P2/80	211E-9902	1
2 06	Spring, valve, diaphragm	P2/81	109E-9907	1
206101	Cover	P2/62	400E-9908	1



PART NO.	DESCRIPTION	PLATE NO.	REMARKS	QTY. REQ.
	CARBURETTOR 2.5 litre - continued		•	
206102	Lockwasher	P2/63	118113-ES	3
206103	Gasket, valve	P2/64	N-9912	2
206104	Diaphragm, valve	P2/65	N-9933	1
206105	Nozzle, No.55	P2/66	2724E-9940A	1
206106	Washer	P2/67	116E-9B539	1
206107	Piston assembly	P2/68	2724E-9554A	1
206108	Lever assembly	P2/69	2724E-9L523B	1
206109	Plug, nozzle	P2/70 '	2724E-9L521A	1
206110	Gasket, float bowl	P2/71	2721E-9564A	1
206111	Shaft, float lever	P2/72	2724E-9558A	1 .
206112	Lever, fast idle ·	P2/73	2724E-9538A	1
206060	Lever, choke	P2/74	2724E-9D542B	1
206114	Gasket, choke body	. P2/75	2724E-9K729A	1
206115	Body	P2/76	2724E-9K728A	1
206118	Washer, choke spindle	P2/78	2724E-9K727A	1
206117	Clip, thermostat retaining	P2/79	111212-ES	3
206118	Piston assembly	P2/80	2724E-9K730A	1
206119	Thermostat assembly	P2/81	2724E-9K731A	1
205844	Chamber, choke assembly	P2/82	2724E-9K732A	1






PART NO.	DESCRIPTION	PLATE NO.	REMARKS	QTY. REQ.
	PIPES AND TANK			
204665	Petrol tank	P3 / 1		1
203036	Filler cap and tube	P3/ 2		1
203043	Hose, petrol filler tube	P3 / 3		1
4437	C'io, hose	P3 / 4		9
205050	Gasket, filler tube	P3 / 5		1
203030	Tank unit	P3 / 6		1
52001	Screw, tank unit to tank	P3 / 7		
333,	Gasket, tank unit	P3 / 8		1
203324	Insulation, petrol tank base	P3/9		1
203325	Insulation, petrol tank back	P3/10		•
204215	Insulation, petrol tank top	P3/11		,
203252	Strap assembly, petrol tank securing	7 37 11		2
103283	Strap, tank securing	P3/12	• • • • • • • • • • • • • • • • • • • •	2
200026	Trunnion tank strap to stud	P3/13	• • • • • • • • • • • • • • • • • • • •	4
200025	Stud. strap to body, rear	P3 /14	• • • • • • • • • • • • • • • • • • • •	2
203264	Stud, strap to body, front	P3/14	• • • • • • • • • • • • • • • • • • • •	2
203326	Insulation, strap	P3/15	• • • • • • • • • • • • • • • • • • • •	2
508825	Nut for strap stud	P3/16	• • • • • • • • • • • • • • • • • • • •	2
5 1 0 0 2 B	Nut for strap stud	-,	• • • • • • • • • • • • • • • • • • • •	4
5::22	Plain washer for strap stud	P3/17	• • • • • • • • • • • • • • • • • •	4
		P3/18	• • • • • • • • • • • • • • • • • • • •	4



PART NO.	DESCRIPTION	PLATE NO.	REMARKS	QTY. REQ.
	FUEL PIPES AND TANK - continued			
200523	Rubber washer for strap stud	P3/19	•••••	
CW300	Coach washer for strap stud	P3/20 ·	• • • • • • • • • • • • • • • • • • • •	7
204666	Filter and feed connection	P3/21	• • • • • • • • • • • • • • • • • • • •	•
51328	Washer, filter and feed connection	P3/22	***************	1
204672	Fuel feed pipe assembly, tank to pump	. 0/22		1
204668	Ferrule, feed pipe	P3/23	• • • • • • • • • • • • • • • • • • • •	1
204667	Tube nut, feed pipe	P3/24		. !
204861	Feed pipe	P3/25	••••••	,
204670	Sleeve, feed pipe	P3/28.	• • • • • • • • • • • • • • • • • • • •	1 .
204673	Fuel return pipe, carburettor to tank	13/20,	• • • • • • • • • • • • • • • • • • • •	'
204662		80 /07	• • • • • • • • • • • • • • • • • • • •	!
8023	Return pipe	P3/27	• • • • • • • • • • • • • • • • • • • •	1
	Sleeve	P3/28	• • • • • • • • • • • • • • • • • • • •	2
200469	Grommet, rear crossmember	P3/29	• • • • • • • • • • • • • • • • • • • •	2
204842	Steady bracket, petrol pipes	P3/30		1
√ 9359	Spire clip, steady bracket	P3/31		1
53171 8	Screw, steady bracket	P3/32		1
205328	Pipe, vent to carburettor	P3/33	2.5 litre	1
8023	Sleeve connection	P3/34	only	1








Valve assembly	QTY. REQ.	REMARKS	PLA Ni	DESCRIPTION	PART NO.
2724E-9350A 2724E-9350A 2724E-9349A 2724E-9349A 2724E-9349A 2724E-9349A 2724E-9349A 2724E-9352 2724E-9352 272557 272				FUEL PUMP	
205969 Kit, pump diaphragm and valve 2724E-9K340 205970 Kit, pump repair 2724E-9349A 205971 Screw, pump upper to lower body P4/1 31612-S7/8 10557 Valve assembly P4/2 105E-9352 10597 Bowl - filter P4/3 E1ADKN-9355 10597 Screen P4/4 E1ADKN-9364 10597 Gasket valve to pump upper body P4/6 E1ADKN-9365 10597 Arm assembly P4/7 2724E-9376A 10597 Washer, rocker arm P4/8 112432-ES8 10597 Spring, rocker arm P4/9 2724E-9380A 10597 Diaphragm P4/10 2724E-9398A		27245 02504		Pump assembly	205968
2724E-9349A				Kit, pump diaphragm and valve	265969
Screw pump upper to lower body			• • • • •	Kit, pump repair	205970
Valve assembly				Screw, gump unger to lower body	205971
Bowl - filter		31612-\$7/8	P4/	Valve assembly	1115
P4/4 E1ADKN-9364 Screen	- · · · · · -	105E-9352	P4/	Rowl of liter	7.78277
1055813 Screen		E1ADKN-9355	P4	Contra	
Gasket valve to pump upper body		E1ADKN-9364A	P4∠	015Ret	
2724E-9367	1	109E-9365	P4/	Screen	3008
105976 Washer rocker arm spacer	2	E1ADKN-9367	P4/	Gasket, valve to pump upper body	105974
105976 Washer rocker arm spacer		2724E-9376A	P4/	Arm assembly	205975
205977 Spring: rocker arm P4/ 9 2724E-9380A 205975 Link: rocker arm P4/10 2724E-9381A 205979 Diaphragm P4/11 2724E-9398A		112432-ES8	P4/	Nasher, rocker arm spacer	105978
135975		2724E-9380A	P4/	Spring, rocker arm	105977
205979 Diaphragm P4/11 2724E-9398A		2724E-9381A	P4/	Link, rocker arm	205978
2724-0000			P4/	Diaphragm	205979
2 00 200 Gasket, pump mounting		2724E-9417A	P4/	Gasket, pump mounting	2 05 98 0
**Carre Chirena hamiliana at		E1ADKN-9387B	P4 /	Stirrup, bowl securing	005816
BOOGS No. 4 Avenue Association		33798-S			50682
Biraha Waahaa ayuun assuuri		34826-S	F4/	Vasher numn securing	5:222

P5






PART NO.	DESCRIPTION	PLATE NO.	REMARKS	REQ.
	AIR CLEANER			
	3 litre and 2.5 litre			•
204528	Air cleaner - 3 litre	•		1
205947	Nut, cover to body			. 2
205948	Washer	. P5/2		2
205949	Gasket, cover			1
205950	Gasket, element			2
205951	Element, air cleaner			1
51130B	Washer, cleaner to carburettor			. 3
204820	Nut, cleaner to carburettor			. 3
205320	Air cleaner - 2.5 litre	•	• • • • • • • • • • • • • • • • • • • •	1
10440	Gasket, filter element	. P5/8		1 2
205944	Element, air cleaner	. P5/9		1
205945	Washer			1
50841B	Nut			1
205946	Sleeve, rubber, cleaner to carburettor	. P5/12		1 ,
_ 55546				_

Q1






PART No.	DESCRIPTION	PLATE NO.	REMARKS	QTY. REQ.
	MAIN BODY AND FITTINGS			
204789	Body shelf	Q1/1		1 .
FG346	Headlamp bezel	Q1/2		2
511208	Washer, headlamp bezel to body	Q1/3		1
51200	Lockwasher, headlamp bezel to hody	01/4	****************	7
50720B	Wing nut, headlamp bezel to body	Q1/5	• • • • • • • • • • • • • • • • • • • •	7
202932	Bumper, front	Q1/6	••••••••••	1
8748	Bolt, front bumper to mounting bracket	Q1/7	••••••••••••	1
204071	Bolt, front bumper to mounting bracket	Q1 / 8	•••••••••••	3 1
51122B	Washer, front bumper to mounting bracket	Q1/9	•••••••••••••	<u> </u>
512	Lockwasher, front bumper to mounting bracket	Q1/10	• • • • • • • • • • • • • • • • • • • •	7
5068	Nut, front bumper to mounting bracket	Q1/11	•••••••••••	7
204004	Mounting bracket, front bumper	Q1/12	• • • • • • • • • • • • • • • • • • • •	•
204129	Shim, mounting bracket	Q1/12 Q1/13		2 As Reg*d.
203247	Spacer, mounting bracket	Q1/14		
51490B	Set screw, mounting bracket to nose support bracket	Q1/14 Q1/15		, NS NBU'U.
51132B	Washer, mounting bracket to nose support bracket	Q1/15 Q1/16	••••••	4
51202B	Lockwasher, mounting bracket to nose support bracket.	Q1/17	• • • • • • • • • • • • • • • • • • • •	4
50682B	Nut, mounting bracket to nose support bracket	Q1/17	• • • • • • • • • • • • • • • • • • • •	4
203960	Bracket, nose support	Q1/18	• • • • • • • • • • • • • • • • • • • •	4
514848	Set screw, bracket to frame	41/19 41/20	• • • • • • • • • • • • • • • • • • • •	2
51202B	Lockwasher, bracket to frame		• • • • • • • • • • • • • • • • • • • •	4
51122B	Washer, bracket to frame	Q1/21	• • • • • • • • • • • • • • • • • • • •	4
FG632	Inspection panel, front wheel arch	Q1/22	• • • • • • • • • • • • • • • • • • • •	4
53743B		Q1/23	• • • • • • • • • • • • • • • • • • • •	4
3611	Screw, inspection panels	Q1/24	• • • • • • • • • • • • • • • • • • • •	40
14854		Q1/25	• • • • • • • • • • • • • • • • • • • •	40
54169K	Backing plate, front seat runner	01/26	• • • • • • • • • • • • • • • • • • • •	4
203515	Rivet, backing plate to body	01/27	• • • • • • • • • • • • • • • • • • • •	8
203513	Door step plate L.H.	Q1/28	• • • • • • • • • • • • • • • • • • • •	1
203314 54170K	Door step plate R.H.	0.400	• • • • • • • • • • • • • • • • • • • •	1
	Rivet, door step plate to body	Q1/29		16
F6717	Access cover, toe box L.H.	Q1/30	R.H.D. only	1
FG7	Access cover, toe box L.H.		L.H.D. only	1
FG71	Access cover, toe box R.H		• • • • • • • • • • • • • • • • • • • •	1



Q [.] 1


			_	•
PART NO.	DESCRIPTION	PLATE NO.	REMARKS	Q T Y R E Q
	BODY SHELL AND FITTINGS - continued			
53173B	Screw, access cover fixing	Q1/31		• •
204831	Tie bracket, door hinge to body L.H	Q1/31	• • • • • • • • • • • • • • • • • • • •	16
204830	Tie bracket, door hinge to body R.H.	41/32	• • • • • • • • • • • • • • • • • • • •	1
0001B	Bolt, tie bracket to body	01 (00		1
51131B	Washer, tie bracket to body	Q1/33	• • • • • • • • • • • • • • • • • • • •	-
51001B		Q1/34	• • • • • • • • • • • • • • • • • • • •	6
	Nut, tie bracket to body	Q1/35	• • • • • • • • • • • • • • • • • • • •	6
1928B	Screw, tie bracket to hinge and hinge to body	Q1/36	• • • • • • • • • • • • • • • • • • • •	2 0
51132B	Washer, tie bracket to hinge and hinge to body	01/37	• • • • • • • • • • • • • • • • • • • •	20
51202B	Lockwasher, tie bracket to hinge and hinge to body	Q1/38	•••••••	2 (
50682B	Nut, tie bracket to hinge and hinge to body	Q1/39	• • • • • • • • • • • • • • • • • • • •	20
202971	Hinge, door L.H.	Q1/40	• • • • • • • • • • • • • • • • • • • •	2
202970	Hinge, door R.H.		• • • • • • • • • • • • • • • • • • • •	2
204754	Door shell assembly L.H	Q1/41	• • • • • • • • • • • • • • • • • • • •	1
204753	Door shell assembly R.H		• • • • • • • • • • • • • • • • • • • •	1
51488B	Set screw, hinge to door	Q1/42	• • • • • • • • • • • • • • • • • • • •	1 6
51202B	Lockwasher, hinge to door	Q1/43	• • • • • • • • • • • • • • • • • • • •	16
51:32B	Washer, hinge to door	Q1/44		16
0682B	Nut, hinge to door	Q1/45		16
FG628	Panel, hinge sealing L.H	Q1/46		1
FG627	Panel, hinge sealing R.H			1
3244B	Screw, hinge sealing panel to door	Q1/47		1.4
205084	Link, door check	Q1/48		2
04 95 0	Lug, link to door	Q1/49		2
200593	Rivet: link to lug	Q1/50		2
200594	Retainer, rivet	Q1/51		2
2764D	Screw, lug to door			
00865	Side plate, link to body			-
00523	Rubber washer, link to side plate	Q1/54		A. P.
200529	Washer, link to side plate	Q1/55		. 2
5 3 8 82 B	Split pin, link to side plate	Q1/58		2
51846B	Screw, side plate to door		•	- 1
51200B	Lockwasher, side plate to door	Q1/57	• • • • • • • • • • • • • • • • • • • •	7
50680B		Q1/58	• • • • • • • • • • • • • • • • • • • •	
	Nut, side plate to door	Q1/59	• • • • • • • • • • • • • • • • • • • •	•
203520	Inspection panel, rear wheel arch	Q1/80	• • • • • • • • • • • • • • • • • • • •	2
203714	Mounting bracket, side, rear bumper	Q1/61	• • • • • • • • • • • • • • • • • • • •	
1442B	Set screw, side mounting bracket to body	01/62	• • • • • • • • • • • • • • • • • • • •	- 1
1121B	Washer, side mounting bracket to body	Q1/63	• • • • • • • • • • • • • • • • • • • •	2
51201B	Lockwasher, side mounting bracket to body	Q1/64		2
50681B	Nut, side mounting bracket to body	Q1/65		2
2 04 07 1	Bolt, side mounting bracket to bumper and bumper		•	
	fixing centre	Q1/66		3
51122B	. Washer, side mounting bracket to bumper and bumper			
	fixing centre	Q1/67		3
51202B	Lockwasher, side mounting bracket to bumper and bumper			
	fixing centre	Q1/68		3
50682B	Nut, side mounting bracket to bumper and bumper		•	•
	fixing centre	Q1/69		3
203220	Rear bumper	01/70		1
203643	Mounting bracket, R.H. rear bumper			1
203644	Mounting bracket, L.H. rear bumper	Q1/71		'
03044 0170B	Bolt, rear mounting bracket to frame	Q1/72		ž
1205B	Lockwasher, rear mounting bracket to frame	Q1/73		2
03641	Spacer, rear mounting bracket to frame	Q1/74		
03642	Grommet, rear mounting bracket to frame			-
8746	Roll humber to rear brooks	Q1/75	• • • • • • • • • • • • • • • • • • • •	2
	Bolt, bumper to rear bracket	Q1/76	• • • • • • • • • • • • • • • • • • • •	4
1122B	Washer, bumper fixing bolts	Q1/77	• • • • • • • • • • • • • • • • • • • •	4
1202B	Lockwasher, bumper fixing bolts	Q1/78	• • • • • • • • • • • • • • • • • • • •	4
0682B	Nut, bumper fixing bolts	01/79	• • • • • • • • • • • • • • • • • • • •	4
03475	Orip channel	Q1/80	• • • • • • • • • • • • • • • • • • • •	2
4176K	Rivet, drip channel	Q1/81	• • • • • • • • • • • • • • • • • • • •	2
	Watermark seedent access to			
17421 17422	Waterproof sealant, 32°6°° long			





PART NO.	DESCRIPTION	PLATE NO.	REMARKS	QTY. REQ.
	BONNET			
F6427	Bonnet lid shell	Q2/ 1	•	1
203156	Hinge, bonnet, R.H	Q2/ 2	••••••	i
203814	Hinge, bonnet, L.H			1
51442B	Set screw, hinge to-lid	Q2/ 3	• • • • • • • • • • • • • • • • • • • •	8
51131 B	Washer, hinge to lid	Q2/ 4	• • • • • • • • • • • • • • • • • •	8
51201B	Lockwasher, hinge to lid	Q2/ 5	• • • • • • • • • • • • • • • • • • • •	8
FG724	Hinge cover L.H	Q2/6		1
FG725	Hinge cover R.H			1
205196	Seal, hinge cover	02/7		2
54170K	Rivet, hinge cover to body	Q2 / 8		16
FG7:5	Cover plate, hinge access	Q2/ 9		2
54170K	Rivet, cover plate fixing	92/10		8
205078	Identification plate	92/11		1
54168K	Rivet, identification plate fixing	Q2/12		Ā
203011	Support stay, bonnet lid	Q2/13		1
53732 B	Screw, support stay to bonnet	Q2/14		. 4
204849	Bracket, support stay	Q2 / 15		1
52040B	Screw, bracket to body	Q2/16		4
51131B	Washer, bracket to body			4
51201	Lockwasher, bracket to body	Q2/18		4
50681	Nut, bracket to body	Q2/19	• • • • • • • • • • • • • • • • • • • •	7





PART NO.	DESCRIPTION	PLATE NO.	REMARKS	QTY REQ
	BOOT			
FG424	Boot lid shell	Q3/ 1	••••	1
8617	Hinge, R.H. boot lid	Q3/ 2		1
8618	Hinge, L.H. boot lid	Q3/3		1
144	Set screw hinge to boot lid	Q3/ 4		6
113	Washer, hinge to boot lid	Q3/ 5		6
1201B	Lockwasher, hinge to boot lid	Q3/6		6
03480	Support stay, boot lid	Q3/ 7		1
3732B	Screw support stay	Q3/ 8		A
3394	Stiker boot lid	Q3/ 9		1
923 B	Set screw, striker to lid	Q3/10		,
200B	Lockwasher, striker to lid	Q3/11	•••••	2
3446	Lock boot	Q3/12		1
452B	Set screw, lock fixing	Q3/13		:
131B	Washer, lock fixing	03/14		2
201B	Lockwasher, lock fixing	Q3/15		2
3481	Support bracket, boot lock	Q3/16		1
923 B	Screw, bracket fixing	Q3/17	••••••	2
200B	Lockwasher, bracket fixing	Q3/18		2
06 8 0 B	Nut. bracket fixing	Q3/19	****	2
2955	Push button, boot lock	Q3/20		1
4850	Key	Q3/21		2
3455	Plunger, boot lid release	Q3/22		. 1
943D	Screw, plunger fixing	Q3/23		2
130B	Washer, plunger fixing	Q3/24		2
200B	Lockwasher, plunger fixing	Q3/25		2
580	Nut, plunger fixing	Q3/28		2
64 2	Cover panel, spare wheel	Q3/27		4




$\mathbf{\cap}$	
u	J

PART NO.	DESCRIPTION	PLATE NO.	REMARKS	QTY. REQ.
	BOOT - continued	•		
0.010.70		00 /00		
201376	Sliding bolt, cover panel	03/28	Factor was taken	1
54176K	Rivet, sliding bolt	Q3/29 (Early vehicles only	. 4
51146B	Washer, sliding bolt rivet	03/30	,	4
205281	Rotor, spare wheel cover catch	Q3/53 }		1
205282	Grommet, spare wheel cover catch	Q3/54		1
205283	Cam, spare wheel cover catch	Q3/55		1
2 05284	Thumb key, spare wheel cover catch	Q3/56 L	Later vehicles	1
205285	Plate, spare wheel cover catch	Q3/57	only	1
205279	Plate, catch mounting	Q3/58		1
54170K	Rivet, plates to body²	Q3/59		8
204249	Foam lining, spare wheel cover tools recess	40,00,		•
204274	Clip, jack handle retaining	Q3/31		. 1
51844B	Screw, clip to spare wheel cover	Q3/32		1
51130B	Washer, clip to spare wheel cover	Q3/33		2
51000B	Nut, clip to spare wheel cover	Q3/34		1
203538	Lining panel	Q3/35		1
203507	Mounting plate, lining panel	Q3/36 1		4
54170K	Rivet, panel to mounting plate	93/37		6
54560H	Cup washer, rivet	03/38	Early vehicles	. 6
3430011	oup washer, 1146t	43/38 (only	U
53256D	Screw, lining panel fixing	Q3/39		7 .
54562H	Cup washer, screw	93/40		7
205280	Stiffener, lining panel	Q3/60)		1
54170K	Rivet, stiffener to panel	40700	Later vehicles	4
51145B	Washer, stiffener to panel	}	only	Ā
53736B	Screw,			4
203401	Inspection lamp complete with mercury switch	Q3/41		1
17353	Bulb inspection lamp	Q3/42	***************************************	1
54168K	Rivet, lamp fixing	03/43		2
200468	Grommet, inspection lamp cable	Q3/44		.2
FG537	Cover, inspection lamp	Q3/45		. 1
53171B	Screw, inspection lamp cover fixing	Q3/46		2
FG533	Cover, rear lights, L.H.	Q3/47		1
FG532	_	43/41		i
203650	Cover, rear lights R.H.	00/40	• • • • • • • • • • • • • • • • • • • •	1 6
203630	Rubber buffer, boot lid seating	Q3/48		0
203981	Weatherstrip	Q3/49 Q3/50	•••••	1
203981		43/50	• • • • • • • • • • • • • • • • • • • •	1
203977	Letter 'C'		• • • • • • • • • • • • • • • • • • • •	1
			• • • • • • • • • • • • • • • • • • • •	2
203973	Letter 'l'			1
203979	Letter 'M'			
203976	Letter 'T'		• • • • • • • • • • • • • • • • • • • •	1
203974	Letter 'A'		• • • • • • • • • • • • • • • • • • • •	1
203970	Letter 'R'		• • • • • • • • • • • • • • • • • • • •	1
204749	Motif *3 litre*	51	• • • • • • • • • • • • • • • • • • •	1
4213	Clip, motif fixing	Q3/52		23

Q4






PART NO.	DESCRIPTION	PLATE NO.	REMARKS	QTY. REQ.
	SIDE DOOR			
204754	Shell, door, L.H	Q4/ 1	••••••	1
204753	Shell, door, R.H			1
202936	Lock, door, L.H	Q4/ 2		1
202 <u>93</u> 5	Lock, door, R.H		• • • • • • • • • • • • • • • • • • • •	1
202	Dovetail, lock, L.H	Q4/ 3		1
2025-3	Dovetail, lock, R.H			1
51880B	Screw, lock and dovetail	Q4/ 4		- 6
202938	Striker, L.H	Q4/ 5		1
202937	Striker, R.H			
202941	Anti-burst plate, L.H	Q4/ 6		1
202940	Anti-burst plate, R.H			1
51886 B	Screw, striker and anti-burst plate to door	Q4/ 7		6
6798	Remote control, L.H	Q4/8		1
6797	Remote control, R.H			1
18778	Screw, remote control_anti-lock		Driver's side only	1
52922B	Screw, remote control to door	Q4/ 9		6
51250B	Lockwasher, remote control to door	Q4/10		6
204319	Link, remote control to lock	Q4/11		2
6892	Insulation, link	Q4/12		2
200593	Rivet, link to remote control	Q4/13		2
200594	Retainer, rivet	Q4/14		2
200647	Waved washer, link to lock	Q4/15		2
7823	Retainer, link to lock	Q4/16		2
202952	Exterior handle	04/17		2
53262B	Screw, door handle fixing	Q4/18		2
51402B	Set screw, door handle fixing	Q4/19		2
511	Washer, door handle fixing	04/20	• • • • • • • • • • • • • •	2
512008	Lockwasher, door handle fixing	04/21		4




PART NO.	DESCRIPTION	PLATE NO.	REMARKS	QTY. REQ.
	DOOR - continued			
204757	Pivot vent and frame, L.H	Q4/22		,
204756	Pivot vent and frame, R.H.	44/22	***********	1
51201B	Lockwasher, vent base to door	04/23	•••••••	1
7623	Washer, vent base to door		•••••••	4
200749	Nut, vent base to door	Q4./24	••••••	4
51848D	Set screw, vent to door	Q4/25	• • • • • • • • • • • • • • • • • • • •	4
51130B	Wacher went to door	Q4/26		4
51200B	Washer, vent to door	Q4/27	• • • • • • • • • • • • • • • • • • • •	4
50680B	Nut want to door	Q4/28	• • • • • • • • • • • • • • • • • • • •	4
202980	Nut, vent to door	Q4/29	• • • • • • • • • • • • • • • • • • • •	4
202979	Drop glass assembly, L.H		• • • • • • • • • • • • • • • • • • • •	1
	Orop glass assembly, R.H.		• • • • • • • • • • • • • • • • • • • •	1
202961	Drop glass	Q4/30	• • • • • • • • • • • • • • • • • • • •	2
6787	Regulator channel L.H. 3	Q4/31		1
6793	Regulator channel R.H		• • • • • • • • • • • • • • • • • • • •	1
5489	Glazing strip	Q4/32	••••••	1
204852	Plate, window regulator mounting	Q4/33	• • • • • • • • • • • • • • • • • • • •	2
202944	Window regulator, L.H	Q4/34		1
202943	Window regulator, R.H			1
52941B	Screw, plate and regulator to door	Q4/35		14
51201B	Lockwasher, plate and regulator to door	Q4/36		14
50681B	Nut, plate and regulator to door	Q4/37		14
4702	Orop glass stop	Q4/38		. 2
51690B	Screw, stop to door	Q4/39		2
51131B			• • • • • • • • • • • • • • • • • • • •	_
	Washer, stop to door	Q4/40	• • • • • • • • • • • • • • • • • • • •	2
51130B	Washer, stop to door	Q4/41	• • • • • • • • • • • • • • • • • • • •	2
51000B	Nut, stop to door	Q4/42	• • • • • • • • • • • • • • • • • • • •	2
204794	Door casing, R.H. upper		• • • • • • • • • • • • • • • • • • • •	1
204795	Door casing, L.H. upper	Q4/43		1
204913	Door casing assembly, L.H. centre	04/44	• • • • • • • • • • • • • • • • • • • •	1
204915	Outer casing, L.H	Q4/45	• • • • • • • • • • • • • • • • • • • •	1
204917	Inner casing, L.H	04/46	• • • • • • • • • • • • • • • • • • • •	1
204918	Lower casing, L.H	Q4/47		1
264912	Door casing assembly, R.H. centre			. 1
204914	Outer casing, R.H			1
204916	Inner casing, R.H.			1
204918	Lower casing, R.H	•		i
54168K	Rivet, lower casing to outer casing	Q4/48		8
54168K	Rivet, centre casing to outer casing	47/40		8
		04/40	• • • • • • • • • • • • • • • • • • • •	-
204927 204926	Mounting plate, arm rest, L.H.	04/49	• • • • • • • • • • • • • • • • • • • •	1
	Mounting plate, arm rest, R.H.	04/50		1
52123B	Screw, mounting plate to door	Q4/50	• • • • • • • • • • • • • • • • • • • •	4
51131B	Washer, mounting plate to door	44/51	• • • • • • • • • • • • • • • • • • • •	8
51000B	Nut, mounting plate to door	04/52		4
204294	Arm rest	Q4/53	• • • • • • • • • • • • • • • • • • • •	2
52924B	Screw, arm rest to door	Q4/54		. 4
203184	Retainer, door trim panel	Q4/55		32
204231	Waterproofing, door	Q4/56		2
8942	Wedge, door seal	Q4/57		2
205226	Secondary door seal	Q4/58		4
204295	Handle, remote control	Q4/59		2
202958	Handle, regulator	04/60		2
204296	Escutcheon, handles	Q4/81		4
52924D				•
9343	Screw, handles	04/62	• • • • • • • • • • • • • • • • • • • •	4
	Lockwasher, handles	Q4/63	• • • • • • • • • • • • • • • • • • • •	. 4
8126	Washer, handles insulating	Q4/64	• • • • • • • • • • • • • • • • • • • •	4
203197	Weatherstrip	Q4/65	• • • • • • • • • • • • • • • • • • • •	2
201842	Weatherstrip	Q4/66	• • • • • • • • • • • • • • • • • • • •	2
51844B	Screw, window frame	Q4/67	• • • • • • • • • • • • • • • • • • • •	12
51130B	Washer, window frame	Q4/68		12
51000 B	Nut, window frame	Q4/69	• • • • • • • • • • • • • • • • • • • •	12
203733	Bracket, window frame	Q4/70		2
204940	Backing plate, vent	04/71	************	2
51848D	Set screw, vent to door	04/72		4
		- · · -		





	GLASSES AND SEALS			REQ.
		_		
202959	Windscreen glass	Q5/ 1	R.H.D. only	1
205104	Windscreen glass		L.H.D. only	1
203957	Weatherstrip, windscreen	Q5/ 2	R.H.D. only	1
204935	Weatherstrip, windscreen		L.H.D. only	1
203499	Filler strip, windscreen	Q5/ 3		1
203166	Rear quarterlight, L.H	Q5/ 4		1
203163	Rear quarterlight, R.H			1
53084D	Screw, rear quarterlight to body	Q5/ 5		10
2 03 7.25	Toggle, rear quarterlight to body	Q5/ 6		2
205	Bracket, toggle	Q5/ 7		2
2 05458	Screw, bracket to glass	Q5/ 8		2
205460	Grommet, bracket to glass	Q5/ 9		2
205459	Nut, bracket to glass	Q5/10		2
205461	Lockwasher, bracket to glass	Q5/11		2
53722D	Screw. toggle to body	Q5/12		8
203723	Screw, toggle pivot	Q5/13		2
203724	Nut toggle pivot	Q5/14		2
205102	Seal. rear quarterlight, L.H	Q5/15		1
205101	Seal, rear quarterlight, R.H			1
202960	Backlight'glass			1
203958	Weatherstrip, backlight	Q5/17		1
8714	Filler strip, backlight	Q5/18		1
	DOOR - continued from overleaf			
51130B	Washer, vent to door	Q4/73		4
51200B	Lockwasher, vent to door	Q4/74		4
5068 08	Nut, vent to door	Q4/75		4
203730	Washer, insulating, link to remote control	04/76		2
205419	Pad, finisher	04/77		2
204828	Bracket, casing	04/78		2
5416	Rivet, bracket	04/79		4
2050	Seal, draught excluding, R.H.	04/80		1
205100	Seal, draught excluding, L.H.	44,00		1
			••••••	•

RELIANT




PART NO.	DESCRIPTION	PLATE NO.	REMARKS	REQ.
	CARPETS AND TRIM			
204853	Set, insulation pads	·	**	1.
204243	Insulation, bulkhead	R1/ 1		2
204855	Insulation, side walls	R1/ 2		2
204856	Insulation, propshaft tunnel	R1/3		1
204857	Insulation, parcel shelf	R1/ 4		2
204858	Insulation, gearbox cover	R1/5		1 .
204859	Insulation, boot floor and wheel arches	R1/6		- 1
204860	Insulation, boot (behind seat)	R1/7		1
204861	Insulation, console, inner	R1/8		1
204862	Insulation, console, outer	R1/9		1
205107	Insulation, floor	R1/10		2
204864	Insulation, rear seat pan	R1/11		1
205108	Insulation, boot millboard	R1/12		1
205310	Floor cover, R.H.	R1/13	R.H.D. only	1
205316	Floor cover, R.H		L.H.D. only	1
205311	Floor cover, L.H	R1/14	R.H.D. only	1 -
205317	Floor cover, L.H.		L.H.D. only	1
204767	Carpet, bulkhead	R1/15		1
204769	Carpet, side wall, L.H	R1/16		1
204768	Carpet, side wall, R.H	.,		1
204770	Carpet, side door step	R1/17		2
205139	Carpet, propshaft tunnel	R1/18		1
203589	Carpet parcel shelf	R1/19	*	1

R1




PA	DESCRIPTION	PLATE No.	REMARKS	QTY. REQ.
CARPETS AND	TRIM - continued			
204214	Cover assembly, petrol filler tube	R1/20	• • • • • • • • • • • • • • • • • • • •	1
203570	Carpet, cover	R1/21	• • • • • • • • • • • • • • • • • • •	1
50680B·	Nut, cover fixing	R1/22	• • • • • • • • • • • • • • • • • • • •	2
51200B	Lockwasher, cover fixing	R1/23		2
51120B	Washer, cover fixing	R1/24		2
203563	Carpet, boot floor, centre	R1/25		1
204099	Carpet, boot side, L.H	R1/26		1
204098	Carpet, boot side, R.H		• • • • • • • • • • • • • • • • • • • •	1
203860	Retaining fillet, rear headlining, R.H	R1/27		1
203861	Retaining fillet, rear headlining, L.H			1
203020	Headlining	R1/28		1
205436	Listing rod, 44% inch	R1/29		1
205437	Listing rod, 45 inch	R1/30		2
205438	Listing rod, 47 inch	R1/31	• • • • • • • • • • • • • • • •	1
53732B	Screw, listing rods	R1/32		8
203572	Trim cloth, centre pillar	R1/33		2
203608	Padding, centre pillar	R1/34		2
2035	Fillet, centre pillar trim	R1/35		2
2035	Trim cloth, screen pillar	R1/36		2
203607	Padding, screen pillar	R1/37		2
203224	Mirror and sun visor assembly			1
203187	Mirror	R1/38		1
203189	Sun visor, plain	R1/39		1
203188	Sun visor, with vanity mirror	R1/40		1
203790	Rod, visor support, long	R1/41		2
203808	Rod, visor support, short	R1/42		2
203791	Retainer, rods	R1/43	• • • • • • • • • • • • • • •	2
52944D	Screw, mirror to mounting bracket	R1/44		1
52 2 4 6 D	Screw, mirror to mounting bracket	R1/45		2
53092B	Screw, visor retainer	R1/46		2

RELIANT



PART NO.	DESCRIPTION	PLATE NO.	REMARKS	QTY. REQ.
	SEATS		•	1.
204866	Rear seat	R2/ 1		1.
CW300	Coachwasher, rear seat securing	R2/ 2	• • • • • • • • • • • • • • •	4
51121B	Washer, rear seat securing	R2/ 3	• • • • • • • • • • • • • •	4
50681B	Nut, rear seat securing	R2/ 4		4
204220	Front seat	R2/ 5	• • • • • • • • • • • • • • • • • • • •	2
203726	Adjusting screw, seat backrest	R2/ 6		4
205298	Sliderail, seat, c.w. catch	R2/ 7	Later vehicles only	
205299	Sliderail, seat plain	R2/8	Later vehicles only	
14854	Backing plate, sliderails to body	R2/ 9	Later vehicles only	
54169K	Rivet backing plate to body	R2/10	Later vehicles only	
W538	Spacer, sliderail	R2/11	Later vehicles only	
2 05 3 1 5	Trim, spacer	R2/12	Later vehicles only	
CW200	Coachwasher, sliderial to body	R2/13	Later vehicles only	8
51001B	Nut, sliderail to body	R2/14	Later vehicles only	
51442B	Set screw, seat to sliderail	R2/15	Later vehicles only	8
5124	Spacer, seat to sliderail	R2/16	Later vehicles only	8
51131B	Washer, seat to sliderail	R2/17	Later vehicles only	8
51001B	Nut, seat to sliderail		Later vehicles only	
200871	Sliderail, seat, c.w. catch	R2/19	Early vehicles only	2
200870	Sliderail, seat, plain		Early vehicles only	
51881B	Screw, seat to sliderail	R2/20	Early vehicles only	16
51001B	Nut, seat to sliderail	R2/21	Early vehicles only	16
204847	Seat runner	R2/22	Early vehicles only	2
50003B	Bolt, seat runner to floor		Early vehicles only	8
51131B.	Washer, seat runner to floor		Early vehicles only	
• •	Backing plate, seat runner		Early vehicles only	
203509	Rivet, backing plate to floor		Early vehicles only	
54169K 205353	Safety harness c.w. fixings		Early vehicles only	
			• *	





PART NO.	DESCRIPTION	PLATE NO.	REMARKS	QTY. REQ.
	FASCIA AND CONSOLE			
204875	Fascia assembly	•	R.H.D. only	. 1
204876	Fascia	R3/ 1		1
204837	Cover, fascia	R3/ 2		1
2 0 5	Fascia assembly		L.H.D. only	1
205181	Fascia			1
204877	Cover, fascia			- 1
204878	Bracket, fascia to body	R3/3		4
54160K	Rivet, bracket to body	R3/ 4		8
52764B	Screw, bracket to fascia	R3/ 5		4
51131B	Washer, bracket to fascia	R3/6		4
2.04885	Fascia end, assembly, R.H			1
204887	Fascia end, R.H	R3/7		1
204889	Cover, fascia end	R 3./. 8		1
204886	Fascia end assembly, L.H			1
204888	Fascia end, L.H			1
204889	Cover, fascia end			1 .
204881	Lid, glove compartment	R3/ 9	R.H.D. only	1
205182	Lid		L.H.D. only	1
204844	Hinge rod, lid	R3/10		1
18788	Spacer, hinge	R3/11		2
204949	Spacer, glove compartment lid	R3/12		1
204883	Cover, glove compartment lid, complete with pull tag.	R3/13		1
54169K	Rivet, pull tag to 4id	R3/14		2
51145B	Washer, pull tag to lid	R3/15		2
203	Lock, set, glove compartment			1
	Lock	R3/16		1
	Bracket, lock securing	R3/17		1




PART NO.	DESCRIPTION	PLATE No.	REMARKS	QTY. REQ.
	FASCIA – continued			
	Screw, bracket to lock	R3/18		1
	Washer, bracket to lock	R3/19	•••••	1
204840	Plate, lock mounting	R3/20	• • • • • • • • • • • • • • • • • • • •	1
204839	Striker, glove compartment lock	R3/21		1
53171D	Screw, striker to compartment	R3/22		` 2
204989	Lining, glove compartment	R3/23	• • • • • • • • • • • • • • • • • • • •	1
F6665	Inspection cover, glove compartment	R3/24	• • • • • • • • • • • • • • • • • • • •	3
204900	Lining, inspection cover	R3/25	•	1
53171D	Screw, inspection cover to compartment	R3/26	• • • • • • • • • • • • • • • • • • • •	2
204901 FG666	Crash pad, upper	R3/27		;
204902	Padding, crash pad	R3/27		1
204902	Padding, crash pad	R3/28		i
204904	Resiliant nosing, crash pad	R3/30		i
204905	Cover, crash pad	R3/31		1
54371	Weld bolt, crash pad fixing	R3/32		2
50881B	Nut, weld bolt to crash pad	R3/33		2
204825	Support bracket, crash pad	R3/34		1
205033	Support bracket, crash pad	R3/35		1
51131B	Washer, crash pad to support bracket	R3/36		2
51201B	Lockwasher, crash pad to support bracket	R3/37	• • • • • • • • • • • • • • • • • • • •	2
50721B	Wing nut, crash pad to support bracket	R3/38	• • • • • • • • • • • • • • • • • • • •	. 2
53333C	Screw, support bracket to body	R3/39	• • • • • • • • • • • • • • • • • • • •	. 2
52002C	Screw, support bracket to facia	R3/40		2
50680C	Nut, support bracket to facia		• • • • • • • • • • • • • • • • • • • •	2
51200C	Washer, support bracket to facia		• • • • • • • • • • • • • • • • • • • •	2
204906	Crash pad assembly, lower	Bo /41	• • • • • • • • • • • • • • • • • • • •	1
F6667	Crash pad	R3/41 R3/42		
204907 204908	Padding, crash pad	R3/42		1
204909	Cover, crash pad	R3/44		i
54170K	Rivet, crash pad lower to body	R3/45		7
51145B	Washer, crash pad lower to body	R3/48		7
20503	Joint coverstrip, crash pad ends	R3/47		2
204788	Console assembly complete with lid			1
204550	Console assembly			1
204787	Console	R3/48		1
204554	Lining, console	R3/49	••••••	. 1
204550	Console lid assembly			1
FG619	Lid	R3/50		1
204551	Padding	R3/51	• • • • • • • • • • • • • • • • • • • •	1
204552	Cover	R3/52	• • • • • • • • • • • • • • • • • • • •	1 -
204553	Lining	R3/53	• • • • • • • • • • • • • • • • • • • •	1
204541	Hinge, lid to console	R3/54	* • • • • • • • • • • • • • • • • • • •	1 2
51130B	Washer, hinge to console	R3/55		. 2
54105K	Rivet, hinge to console	R3/56 R3/57		2
205029	Screw, hinge to lid	R3/5/		2
54561H	Cup washer, hinge to lid	R3/58		2
204253	Lockwasher, hinge to lid,	R3/60		2
204252	Nut, hinge to lid	R3/61		2
53744D 53345D	Screw, console rear to body	R3/62		2
51121B	Washer, console to facia			2
51201B	Lockwasher, console to facia			2
50721B	Wing nut, console to facia			2
204835	Switch panel			1
204896	Cover, switch panel	_		1
53242D	Screw, panel to console	R3/68		. 2
204894	Captive nut, panel to console	R3/69		2
4687	Grommet, gear lever			1
204684	Ash tray	R3/71		1
	Screw, ash tray fixing			1
53748D	Screw, facia lower to body inner	R3/73		2

S 1

Heater & Fresh Air System





PART NO.	DESCRIPTION	PLATE No.	REMARKS	QTY. REQ.
	HEATER			
204932	Heater Kit			
205	Heater	\$1/1	••••••	1
2055	Nozzle, demister	\$1/2		
205363	Hosé, demister	S1/ 2 S1/ 3	•••••	2
205364	Elbow hose, demister hose	S1/ 3 S1/ 4	• • • • • • • • • • • • • • • • • • • •	2
205365	, Tube, elbow to hose	\$1/ 4 \$1/ 5	• • • • • • • • • • • • • • • • • • • •	2
225366	Clip, hose to tube and nozzle	\$1/ B	•••••	2
200408	Clip, elbow to heater	\$1/ B \$1/ 7	• • • • • • • • • • • • • • • • • • • •	4
203221	Rotary control, temperature		•••••••	2
18373	Rotary control, distribution	S1/ 8	•••••	
18375	Escutcheon, temperature control	04 (4	• • • • • • • • • • • • • • • • • • • •	1
18376	Escutcheon, distribution control	S1/ 9	••••••	1
18364	Knob, heater controls	04.44	•••••	1
205367	Cable, distribution control to heater	\$1/10	••••••	2
18374	Truncian cable to bester	\$1/11	• • • • • • • • • • • • • • • • • • • •	1
18377	Trunnion, cable to heater	\$1/12	• • • • • • • • • • • • • • • • • • • •	1
205331	Screw, cable to trunnion	\$1/13	• • • • • • • • • • • • • • • • • • •	1
18374	Cable, temperature control to water valve	\$1/14	• • • • • • • • • • • • • • • • • • • •	1
	Trunnion, cable to water valve	S1/15	• • • • • • • • • • • • • • • • • • • •	1
18377	Screw, cable to trunnion	S1/16	•••••	. 1
201099	Water valve	S1/17	• • • • • • • • • • • • • • • • • • • •	1
205368	Adaptor, water valve to engine	\$1/18	• • • • • • • • • • • • • • • • • • • •	1
205369	Hose, water valve to heater	\$1/19		1
205370	Hose, heater to water pump	\$1/20		1
2004	Clip, water hoses	\$1/21		A




Heater & Fresh Air System

PART NO.	DESCRIPTION	PLATE NO.	REMARKS	QTY. _REQ.
	HEATER continued			
200420	Clip, heater to water pump hose	\$1/22	• • • • • • • • • • • • • • • • • • • •	2
200430	Caution label	\$1/23	• • • • • • • • • • • • • • • • • • • •	1
51442B	Set screw, heater fixing	S1/24		4
51201B	Lockwasher, heater fixing	\$1/25		4
204930	Backing plate, heater	S1/26		2
54168K	Rivet, backing plate to body	\$1/27		4
FG692	Heater outlet L.H	\$1/28		1
FG687	Heater outlet, R.H			1
53743B	Screw,	\$1/29		8
53181B	Screw, demister to body	51/30		4
203143	Bezel nut, rotary control	\$1/31		2
541-68K	Rivet, caution label fixing	\$1/32	•••••	2
	FRESH AIR SYSTEM			
204759	Adjustable nozzle fresh alr	\$1/33		2
53162B	Screw, nozzle to fascia	\$1/34		8
205008	Hose, fresh air	\$1/35		2
	Clip, hose to nozzle		4	2
205 007	Stub pipe, fresh air	\$1/37		2
2 05 0 0 4 5 4 1 6 8 K	Rivet, stub pipe fixing	\$1/38		8
341004	without ages hibs		4	

T1






PART NO.	DESCRIPTION	PLATE NO.	REMARKS	QTY. REQ.
	STARTER MOTOR			
205358	Starter motor		3004E-11001A	1
205981	Lever, drive		C2DF-11067A	1
205982	Pin, lever		73266-\$	t
205983	Spring, return	T1// 3	C2DF-11103A	- L
205984	Cover	T1/ 4	C2DF-11058A	1
205985	Gasket, cover		C2DF-11065A	1
205986	Housing, drive end	11/ 6	3008E-11130A	- 1
50100B	Bolt, motor to clutch housing	T1/7	20408-\$7/8	2
205	Washer	T1/8	34847-ES2	2
205	Drive assembly		C6FF-11350A	1
205988	Sleeve, coil retaining		C2DF-11105A	1
205989	Flange, coil retaining		C2DF-11106A	1
205990	Washer, thrust		C2DF-11035A	1
205991	Armative	T1/13	C4DZ-11005A	1
205992	Ring, stop		C2DZ-11222A	1
205993	Retainer, stop ring	T1/15	C2DZ-11223A	1
205811	Nut. switch terminal	T1/16	33923-\$7/8	2
200324	Lockwasher		34806-\$7/8	1
205994	Washer, insulator	T1/18	18-11094B	. 1
205995	Washer		B5A-11095A	1
205996	Screw, pole piece	T1/20	C2DF-11415-A	3
205997	Brush assembly	T1/21	C6FF-11056A/B	1
51682C	Screw, brush	T1/22	25231-\$7	2
205998	Insulator	T1/23	C2DZ-11107A	2
205999	Washer	T1/24	C2D7-11093-B	1
206000	Terminal	T1/25	C2DZ-11102D	1
206000	Coil assembly	T1/26	C6FF-11082A	. 1
206001	Brush	T1/27	C6FF-11055A	1
206002	Band, cover, assembly	T1/28	C6FF-11126A	1
52 01 0B	Screw	T1/29	27177-\$8	1

T1

PART NO.	DESCRIPTION	PLATE NO.	REMARKS	QTY. REQ.
	STARTER MOTOR - continued			
206004	Nut	Ti/30	34141-58	1
2 06 0 0 5	Plate, end, assembly	T1/31	C3DZ-11050A	1
206006	Spring	T1/32	C2DZ-11059A	4
206007	Bolt, frame, through	T1/33	C2DF-11091A	2
2 06 0 0 8	Washer	T1/34	358842-\$	2

7









Alternator	PART NO.	DESCRIPTION	PLATE _NO.	REMARKS	QTY. REQ.
17527 Bolt, through fixing +:	٠				
17535	16970	Alternator	·	• • • • • • • • • • • • • • • • • • • •	
17598	17527	Bolt, through fixing 4:	T2/1	• • • • • • • • • • • • • • • • • • • •	2
17491 Bracket, drive end	17535			• • • • • • • • • • • • • • • • • • • •	1
17481	17599	Washer, shaft	. T2/3		1
17485	17534	•			1
17544	17491	Bracket, drive end			1
17480	17465			• • • • • • • • • • • • • • • • • • • •	1
18871 Distance collar, drive end 12/10 1 17/10 1 17/17 17/17 Relainer, bearing ring; 12/11 1 1 1 1 1 1 1 1 1	17544				1
18871 Distance coller, drive end 72/10 1 17475 Retainer, bearing ring ; 72/11 1 1 1 1 1 1 1 1 1	17480		. ,		1
17475 Retainer, bearing ring ;	17489				1
17418		·			1
17488 Sieeve, S.R.E. bracket adjustment				•	1
17482 Bracket, slip ring end T2/14 T17483 Seat T2/15 T2/15 T1/484 Heatsink (with cathode base diodes) T2/16 T1/484 Heatsink (with anode base diodes) T2/17 T1/481 T1/481 Brush, spring and Lucar T2/18 T2/18 T2/18 T1/480 Brushbox T2/19 T1/480 T1/480 Brushbox T2/19 T1/480 T1/480 Brushbox T2/29 T1/485 T1/485 Sleeve insulating, Lucar Cutout T1/20 T1/485 Sleeve insulating, Lucar Cutout T1/20 T1/485 Sleeve insulating, cutout terminal T1/22 T1/485 Sleeve insulating T1/480 T					1
17493					1
17484	17492				1
17442	17493			• • • • • • • • • • • • • • • • • • • •	1
17481 Brush, spring and Lucar 12/18 2 17490 Brushbox 172/19 1 1 1 1 1 1 1 1 1	17494			• • • • • • • • • • • • • • • • • • • •	1
17490 Brushbox		•		• • • • • • • • • • • • • • • • • • • •	1
201572	17481			****	. 2
17478	17490			******	1
17485 Steeve insulating, cutout terminal T2/22 17591 Washer, insulating T2/23 17529 Terminal cutout T2/24 17583 Screw heatsink fixing T2/25 17582 Washer, insulating T2/25 17476 Stator T2/27 T2/27 T17486 Stator T2/27 T17486 Fan T2/28 T2/27 T17486 Fan T2/28 T2/27 T17486 Fan T2/28 T2/29 T2/25 T17486 Fan T2/28 T2/29 T2/25 T17486 Fan T2/28 T2/29 T2/25 T17486 T2/28 T2/29 T2/25 T17486 T2/28 T2/29 T2/25 T17486 T2/29 T2/25 T17486 T2/29 T2/29 T2/25 T17486 T17486 T2/25 T17486 T2/25 T17486 T2/25 T17486 T2/25 T1725 T2/25 T17486 T2/25 T1725 T2/25 T17486 T2/25 T1726 T2/25 T2/25 T1726 T2/25 T2/25 T2/25 T172	201572	Connector, Lucar cutout		• • • • • • • • • • • • • • • • • • • •	. 1
17591 Washer, insulating	17479				1
17529 Terminal cutout	17485	Sleeve insulating, cutout terminal		• • • • • • • • • • • • • • • • • • • •	1
17583 Screw heatsink fixing T2/25 1 17592 Washer, insulating T2/26 1 17476 Stator T2/27 1 17482 Sundry parts set T2/27 1 17488 Fan T2/28 1 17486 Fan T2/28 1 17486 Fan T2/29 2725E-10145-B 1 17486 T3/29 T	17591	Washer, insulating	-	• • • • • • • • • • • • • • • • • • • •	1
17592 Washer, insulating	17529	Terminal cutout		• • • • • • • • • • • • • • • • • • • •	1
17476	17583	Screw, heatsink fixing	. T2/25	• • • • • • • • • • • • • • • • • • • •	1
17486	17592	Washer, insulating		• • • • • • • • • • • • • • • • • • • •	1
17486	17476		-		1
205548 Arm, alternator belt adjusting T2/29 2725E-10145-B 1 50064 Bolt, arm to alternator T2/30 20466-S2 1 51222B Lockwasher, arm to alternator T2/31 34808-S7/8 1 51133B Washer, arm to alternator T2/32 44724-S7/8 1 50882B Nut, arm to alternator T2/33 34443-ES 1 205547 Guard, alternator fan T2/34 2400E-10K309-A 1 205548 Pulley, alternator T2/35 2400E-10K309-B 1 205549 Bracket, alternator mounting T2/36 2725E-10039-B 1 50062B Bolt, mounting bracket to cylinder head T2/36 2725E-10039-B 1 50080B Bolt, mounting bracket to cylinder head T2/37 20426-S2 1 50079B Bolt, mounting bracket to cylinder head T2/39 20486-S2 1 51222B Lockwasher, mounting bracket bolt T2/40 34806-S7/8 3 50062B Bolt, alternator adjusting arm to cylinder head T2/41 <td>17482</td> <td>· ·</td> <td></td> <td></td> <td></td>	17482	· ·			
50064 Bolt, arm to alternator T2/30 20466-S2 1 51222B Lockwasher, arm to alternator T2/31 34806-S7/8 1 51133B Washer, arm to alternator T2/32 44724-S7/8 1 50882B Nut, arm to alternator T2/33 34443-ES 1 205547 Guard, alternator fan T2/34 2400E-10K309-A 1 205548 Pulley, alternator T2/35 2400E-10K309-A 1 205549 Bracket, alternator mounting T2/35 2400E-10K309-B 1 50062B Bolt, mounting bracket to cylinder head T2/36 2725E-10039-B 1 50060B Bolt, mounting bracket to cylinder head T2/37 20426-S2 1 50079B Bolt, mounting bracket to cylinder head T2/38 20386-S2 1 51222B Lockwasher, mounting bracket bolt T2/40 34806-S7/8 3 50062B Bolt, alternator adjusting arm to cylinder head T2/41 20426-S2 1 51222B Lockwasher, alternator to mounting bracket	17486	•			•
51222B Lockwasher, arm to alternator T2/31 34806-S7/8 1 51133B Washer, arm to alternator T2/32 44724-S7/8 1 50882B Nut, arm to alternator T2/33 34443-ES 1 205547 Guard, alternator fan T2/34 2400E-10K309-A 1 205548 Pulley, alternator T2/35 2400E-10K309-B 1 205549 Bracket, alternator mounting T2/36 2725E-10039-B 1 50082B Bolt, mounting bracket to cylinder head T2/37 20426-S2 1 50080B Bolt, mounting bracket to cylinder head T2/38 20388-S2 1 50079B Bolt, mounting bracket to cylinder head T2/39 20486-S2 1 51222B Lockwasher, mounting bracket bolt T2/40 34808-S7/8 3 50062B Bolt, alternator adjusting arm to cylinder head T2/41 20426-S2 1 51222B Lockwasher, alternator to mounting bracket T2/43 20487-S2 1 205551 Bolt, alternator to mounting bracket	205546	Arm, alternator belt adjusting	•		-
51133B Washer, arm to alternator T2/32 44724-S7/8 1 50882B Nut, arm to alternator T2/33 34443-ES 1 205547 Guard, alternator fan T2/34 2400E-10K3 09-A 1 205548 Pulley, alternator T2/35 2400E-10K3 09-A 1 205549 Bracket, alternator mounting T2/36 2725E-1003 9-B 1 50082B Bolt, mounting bracket to cylinder head T2/37 20426-S2 1 50080B Bolt, mounting bracket to cylinder head T2/38 20386-S2 1 50079B Bolt, mounting bracket to cylinder head T2/39 204 86-S2 1 51222B Lockwasher, mounting bracket bolt T2/40 34806-S7/8 3 50062B Bolt, alternator adjusting arm to cylinder head T2/41 20426-S2 1 51222B Lockwasher, alternator adjusting arm to cylinder head T2/41 20426-S2 1 505551 Bolt, alternator to mounting bracket T2/43 20487-S2 1 205552 Bolt, alternator to mounti	50064	Bolt, arm to alternator	. T2/30	20466-S2	1
50882B Nut, arm to alternator T2/33 34443-ES 1 205547 Guard, alternator fan T2/34 2400E-10K309-A 1 205548 Pulley, alternator T2/35 2400E-10A353-B 1 205549 Bracket, alternator mounting T2/36 2725E-10039-B 1 50082B Bolt, mounting bracket to cylinder head T2/37 20426-S2 1 50080B Bolt, mounting bracket to cylinder head T2/38 20386-S2 1 50079B Bolt, mounting bracket to cylinder head T2/39 20486-S2 1 51222B Lockwasher, mounting bracket bolt T2/40 34806-S7/8 3 50062B Bolt, alternator adjusting arm to cylinder head T2/41 20426-S2 1 51222B Lockwasher, alternator adjusting arm to cylinder head T2/41 20426-S2 1 205551 Bolt, alternator to mounting bracket T2/43 20487-S2 1 205552 Bolt, alternator to mounting bracket T2/44 20513-S8 1 51133B Washer, alternator to	51222B	Lockwasher, arm to alternator	. T2/31	34806-\$7/8	1
205547 Guard, alternator fan T2/34 2400E-10K309-A 1 205548 Pulley, alternator T2/35 2400E-10A353-B 1 205549 Bracket, alternator mounting T2/36 2725E-10039-B 1 500828 Bolt, mounting bracket to cylinder head T2/37 20426-S2 1 500808 Bolt, mounting bracket to cylinder head T2/38 20388-S2 1 500798 Bolt, mounting bracket to cylinder head T2/39 20486-S2 1 512228 Lockwasher, mounting bracket bolt T2/40 34808-S7/8 3 500628 Bolt, alternator adjusting arm to cylinder head T2/41 20426-S2 1 512228 Lockwasher, alternator adjusting arm to cylinder head T2/41 20426-S2 1 205551 Bolt, alternator to mounting bracket T2/43 20487-S2 1 205552 Bolt, alternator to mounting bracket T2/44 20513-S8 1 511338 Washer, alternator to mounting bracket T2/45 44724-S7/8 4 205550 Dis	51133B		-		1
205548 Pulley, alternator T2/35 2400E-10A353-B 1 205549 Bracket, alternator mounting T2/36 2725E-10039-B 1 500828 Bolt, mounting bracket to cylinder head T2/37 20426-S2 1 500808 Bolt, mounting bracket to cylinder head T2/38 20388-S2 1 500798 Bolt, mounting bracket to cylinder head T2/39 20486-S2 1 51222B Lockwasher, mounting bracket bolt T2/40 34808-S7/8 3 50062B Bolt, alternator adjusting arm to cylinder head T2/41 20426-S2 1 51222B Lockwasher, alternator adjusting arm to cylinder head T2/41 20426-S2 1 205551 Bolt, alternator to mounting bracket T2/43 20487-S2 1 205552 Bolt, alternator to mounting bracket T2/44 20513-S8 1 51133B Washer, alternator to mounting bracket T2/45 44724-S7/8 4 205550 Distance washer, alternator to mounting bracket T2/46 112439-ES7 1	50882B	Nut, arm to alternator	. T2/33	34443-ES	-1
205549 Bracket, alternator mounting	205547	Guard, alternator fan	. T2/34		1
500628 Bolt, mounting bracket to cylinder head T2/37 20426-S2 1 500808 Bolt, mounting bracket to cylinder head T2/38 20388-S2 1 500798 Bolt, mounting bracket to cylinder head T2/39 20486-S2 1 512228 Lockwasher, mounting bracket bolt T2/40 34808-S7/8 3 500628 Bolt, alternator adjusting arm to cylinder head T2/41 20426-S2 1 512228 Lockwasher, alternator adjusting arm to cylinder head T2/42 34806-S7/8 1 205551 Bolt, alternator to mounting bracket T2/43 20487-S2 1 205552 Bolt, alternator to mounting bracket T2/44 20513-S8 1 511338 Washer, alternator to mounting bracket T2/45 44724-S7/8 4 205550 Distance washer, alternator to mounting bracket T2/46 112439-ES7 1	2 05 5 4 8	Pulley, alternator	. T2/35	2400E-10A353-B	1
50080B Bolt, mounting bracket to cylinder head T2/38 20386-S2 1 50079B Bolt, mounting bracket to cylinder head T2/39 20486-S2 1 51222B Lockwasher, mounting bracket bolt T2/40 34808-S7/8 3 50082B Bolt, alternator adjusting arm to cylinder head T2/41 20426-S2 1 51222B Lockwasher, alternator adjusting arm to cylinder head T2/42 34806-S7/8 1 205551 Bolt, alternator to mounting bracket T2/43 20487-S2 1 205552 Bolt, alternator to mounting bracket T2/44 20513-S8 1 51133B Washer, alternator to mounting bracket T2/45 44724-S7/8 4 205550 Distance washer, alternator to mounting bracket T2/46 112/439-ES7 1	205549	Bracket, alternator mounting	. T2/36		1
500798 Bolt, mounting bracket to cylinder head T2/39 20486-S2 1 512228 Lockwasher, mounting bracket bolt T2/40 34806-S7/8 3 500628 Bolt, alternator adjusting arm to cylinder head T2/41 20426-S2 1 512228 Lockwasher, alternator adjusting arm to cylinder head T2/42 34806-S7/8 1 205551 Bolt, alternator to mounting bracket T2/43 20487-S2 1 205552 Bolt, alternator to mounting bracket T2/44 20513-S8 1 511338 Washer, alternator to mounting bracket T2/45 44724-S7/8 4 205550 Distance washer, alternator to mounting bracket T2/46 112439-ES7 1	50082B	Bolt, mounting bracket to cylinder head	. T2/37	20426-82	1
51222B Lockwasher, mounting bracket bolt T2/40 34808-S,7/8 3 50062B Bolt, alternator adjusting arm to cylinder head T2/41 20426-S2 1 51222B Lockwasher, alternator adjusting arm to cylinder head T2/42 34806-S7/8 1 205551 Bolt, alternator to mounting bracket T2/43 20487-S2 1 205552 Bolt, alternator to mounting bracket T2/44 20513-S8 1 51133B Washer, alternator to mounting bracket T2/45 44724-S7/8 4 205550 Distance washer, alternator to mounting bracket T2/46 112439-ES7 1	50080B	Bolt, mounting bracket to cylinder head	. T2/38		1,
50062B Bolt, alternator adjusting arm to cylinder head T2/41 20426-S2 1 51222B Lockwasher, alternator adjusting arm to cylinder head T2/42 34806-S7/8 1 205551 Bolt, alternator to mounting bracket T2/43 20487-S2 1 205552 Bolt, alternator to mounting bracket T2/44 20513-S8 1 51133B Washer, alternator to mounting bracket T2/45 44724-S7/8 4 205550 Distance washer, alternator to mounting bracket T2/46 112439-ES7 1	50079B	Bolt, mounting bracket to cylinder head			
51222B Lockwasher, alternator adjusting arm to cylinder head T2/42 34806-S7/8 1 205551 Bolt, alternator to mounting bracket T2/43 20487-S2 1 205552 Bolt, alternator to mounting bracket T2/44 20513-S8 1 51133B Washer, alternator to mounting bracket T2/45 44724-S7/8 4 205550 Distance washer, alternator to mounting bracket T2/46 112439-ES7 1	51222B		-		_
205551 Bolt, alternator to mounting bracket T2/43 20487-S2 1 205552 Bolt, alternator to mounting bracket T2/44 20513-S8 1 51133B Washer, alternator to mounting bracket T2/45 44724-S7/8 4 205550 Distance washer, alternator to mounting bracket T2/46 112/49-ES7 1	50062B				1
205551 Bolt alternator to mounting bracket	51222B		T2/42		. 1
51133B Washer, alternator to mounting bracket	205551		. T2/43		
205550 Distance washer, alternator to mounting bracket T2/46 112439-ES7 1	2 05552	Bolt, alternator to mounting bracket			
205550 Distance washer, alternator to mounting bracket T2/46 112439-ES7 1	51133B	Washer, alternator to mounting bracket	. T2/45		4
70 /47 04440 5000 2	205550	Distance washer, alternator to mounting bracket	. T2/46 ·	–	
				34443-ES2C	2





PART NO.	DESCRIPTION	PLATE No.	REMARKS	QTY. REQ.
	DISTRIBUTOR	•		
169	Distributor - early models		*****	
172	Cover, moulded	T3/1		. 1
17243	Rotor arm	T3/ 2		1
7509	Contact set	T3/3		1
7504	Bush, insulating	T3/4	*****	1
7510	Condenser	T3/5		1
7508	Plate, contact breaker base	T3/6		1
7231	Plate, contact breaker bearing	T3/7		1
72 05	Cable, bush and lead	T3 / 8		1
7589	Washer, insulating terminal	T3/ 9		1
7505	Lead, earth	T3/10		1
7247	Cam	T3/11		1
7246	Springs set, automatic advance	T3/12		1
7234	Weights	T3/13		2
7245	Shaft and action plate	T3/14		1
7232	Nut, knurled micrometer	T3/15		1
7233	Spring, ratchet, micrometer	T3/16		1
7209	Spring, return micrometer	T3/17		1
7237	Vacuum unit	T3/18		1
7240	Clip, cap retaining	T3/19		2
7242	Thrust washer	T3/20		1
7503	Sundry parts set		****************	1






PART NO.	DESCRIPTION	PLATE NO.	REMARKS	QTY REC
	WINDSCREEN WIPER MOTOR			
204568	Motor c.w. rack			1
16982	Motor			1
17579	Bolt, through fixing	. T4/ 1		2
17190	Brushgear assembly	T4/ 2		1
17189	Brush set		• • • • • • • • • • • • • • •	2
17576	Spring, brush			1
17197	Plate, switch	T4/3		1
17572	Cover, switch plate	T4/-4		1
17573	Screw, cover	T4/ 5		- 2
17565	Cover, gearbox	T4/6		1
17566	Screw, cover	T4/ 7		2
17567	Rod, connecting	T4/8		1
17188	Shaft and gear	T4/ 9		1
17580	Screw, thrust	T4/10		1
17581	Nut, thrust screw	T4/11		1
7578	Armature	T4/12		1
17582	Rack	T4/13		1








PART NO.	DESCRIPTION	PLATE NO.	REMARKS	QTY. REQ.
	WINDSCREEN WIPER ARMS		-	
204568	Motor, windscreen wiper, c.w. rack	T5/ 1		1
17314	Strap, motor fixing	T5/ 2		. 1
17315	Pad, motor seating	T5/ 3	• • • • • • • • • • • • • • • • • • • •	1
17316	Pressure pad	T5/ 4		3
50681B	Nut, motor fixing	T5/ 5		2
51201B	Lockwasher, motor fixing	T5/ 6		2
51131B	Washer, motor fixing	T5/ 7		2
204569	Bundy, motor to wheelbox	T5/ 8		1
203249	Grommet, bundy	T ₅ / 9		1
202990	Wheelbox	•,		2
17462	Nut, wheelbox fixing	T5/10	• • • • • • • • • • • • • • • • • • • •	2
1719	Bush, front	T5/f1	• • • • • • • • • • • • • • • • •	2
171:	Bush, centre	T5/12	• • • • • • • • • • • • • • • • • • • •	2
17518	Washer	T5/13		2
17192	Bush, rear	T5/14		2
17195	Spindle, gear and boss	T5/15		2
17460	Nut, cover fixing	T5/16		4
202992	Bundy, wheelbox to wheelbox	T5/17		1
5444	Bundy, over-run	T5/18		1
204257	Wiper arm and blade assembly		R.H.D. only	2
204258	Blade	T5/19		2
202994	Arm	T5/20		2
205136	Wiper arm and blade assembly		L.H.D. only	2 '
204258	Blade			2
205135	Arm			2





PART NO.	DESCRIPTION	PLATE NO.	REMARKS	QTY. REQ.
	HEADLAMPS			-
203706	Headlamp assembly, inner		R.H.D. only	2
205115	Light unit, sealed beam	T6/ 1		2
205121	Rim, light unit seating	T6/ 2		· 2
203185	Headlamp assembly, outer	. 0, 2	R.H.D. only	2
205112	Light unit, sealed beam	T6/ 1		2
205122	Rim, light unit seating	TR/ 2		2
205017	Headlamp assembly, inner		U.S.A. only	2
205113	Light unit, sealed beam	T6/ 1		2
205121	Rim, light unit seating	T6/ 2		2
205018	Headlamp assembly, outer		U.S.A. only	2
205114	Light unit, sealed beam	T6/ 1		2
205122	Rim, light unit seating	TB/ 2		2
203186	Headlamp assembly, inner		Europe only	2
205111	Light unit, sealed beam	T6/ 1		2
205121	Rim, light unit seating	T6/ 2		2
205011	Headlamp assembly, outer		* Europe only	2
205116	Light unit	T6/ 3		2
205122	Rim, light unit seating	T6/ 2		2
17822	Bulb	T6/4		2
205120	Spring, bulb retaining	TB/ 5		2


T 6



PART NO.	DESCRIPTION	PLATE No.	REMARKS .	QTY. REQ.
	HEADLAMPS - continued			
203186	Headlamp assembly, inner		Austria only	2
205111	Light unit, sealed beam	T8/ 1		2
205121	Rim, light unit seating	T6/ 2	• • • • • • • • • • • • • • • • • • • •	2
205014	Headlamp assembly, outer		Austria only	2
205110	Light unit	T6/ 3	• • • • • • • • • • • • • • • • • • • •	2
205122	Rim, light unit seating		• • • • • • • • • • • • • • • • • • • •	2
17622	Bulb	T6/ 4	• • • • • • • • • • • • • • • • • • • •	2
205120	Spring, bulb retaining	T8/ 5		2
205012	Headlamp assembly, inner		France only	2
205116	Light unit	T6/ 3		2
205122	Rim, light unit seating	T6/ 2		2
205119	Bulb	T6/ 4	• • • • • • • • • • • • • • • • • • • •	2
205120	Spring, bulb retaining	T6/ 5		2
205013	Headlamp assembly, outer		France only	2
205116	Light unit	T6/ 3		2
205122	Rim, light unit retaining	T6/ 2		2
205119	Bulb	T6/ 4		2
20512	Spring, bulb retaining	T6/ 5		2
20501	Headlamp assembly, inner		Italy only	2
205117	Light unit	T6/ 3		2
205121	Rim, light unit seating	TG/ 2		2
17622	Bulb	T6/ 4		2
	Spring, bulb retaining	T6/ 5		2
205016	Headlamp assembly, outer		italy only	2
205118	Light unit	T6/ 3		2
205122	Rim, light unit seating	T6/ 2		2
17822	Bulb	TB/ 4		2
	Spring bulb retaining	T6/ 5		2
	The following items are common to all headlamps:-			
205123	Rim, light unit retaining	T6/ 6	• • • • • • • • • • • • • • • • • • • •	4
205124	Screw, rim fixing	T6/ 7	R.H.D. only	12
205125	Screw, rim fixing		L.H.D. only	12
205126	Adaptor	T6/ 8		4
205127	Screw, trimmer set	T6/ 9		8
205129	Pin, fixed point	T6/10		. 4
205128	Bush, fixed point pin	T6/11		4
205130	Gasket, lamp seating	T6/12		4
205131	Sleeve, lamp seating	TB/13		8
205132	Body	T6/14		4
53183B	Screw headlamp	•		16
16043	Clip, headlamp			16
10043	vity, meautamy			. 0








PART NO.	DESCRIPTION	PLATE NO.	REMARKS	QTY. REQ.
	SIDE/INDICATOR LAMPS			
201526	Side/indicator lamp R.H			-1
201640	Side/indicator lamp L.H			1.
17048	Rim	T7/ 1		2
17049	Screw, rim fixing	T7/ 2		4
17716	Washer, rim fixing	T7/ 3		4
17050	Lens R.H	T7/ 4		1
17051	Lens L.H			1
17052	Gasket, lens seating	T7/ 5		2
17053	Lens, indicator, amber	T7/ 6		2
17746	Bulb, side	T7/ 7		2
17721	Bulb, indicator	T7/ 8		2
17743	Interior, bulbholder, side	T7/ 9		Ź
17718	Interior, bulbholder, indicator	T7/10		2
17054	Body	T7/11		2
17055	Grommet, cable entry, side	T7/12		. 2
17719	Grommet, cable entry, indicator	T7/13		2
51200B	Lockwasher, lamp fixing	T7/14		4
50880B	Nut. lamp fixing	T7/15		4



PART NO.	DESCRIPTION	PLATE NO.	REMARKS	QTY. REQ.
202986	Stop/Tail lamp assembly		• • • • • • • • • • • • • • • • • • • •	2
17710	Lens, red	T8/11	• • • • • • • • • • • • • • • • • • • •	2
17715	Screw, lens fixing	T8/12		4
17716	Washer, lens fixing	T8/13		4
17713	Bulb	T8/14		2
17717	Gasket, lens seating	T8/15		2
17151	Body	T8/16 -		2
17711	Interior, bulb holder	T8/17		2
17712	Grommet, cable entry	T8/18		2
17720	Gasket, lamp seating	78/19		2
17695	Nut, lens fixing	T8/20		4
50680B	Nut, lamp fixing			4
51200B	Lockwasher, lamp fixing		• • • • • • • • • • • • • • • • • • • •	4
5844	Number plate illumination lamp assembly c.w. fixings .			1
201028	Body	T8/21		1
17172	Lens	T8/22		1
17173	Gasket, lens seating	T8/23		1
17746	Bulb	T8/24		2
50680B	Nut, lamp fixing			4
51200B	Lockwasher, lamp fixing			4
2 02 98 8	Reflector		Not illustrated .	2
203844	Screw, reflector to body			
51145B	Washer, reflector to body			
203845	Nut, reflector to body			
50680B	Nut, lamp fixing			4
51200B	Lockwasher, lamp fixing			4







PART NO.	DESCRIPTION	PLATE NO.	REMARKS	QTY. REQ.
	STOP/TAIL, INDICATOR, NUMBER PLATE & REVERSING LAMPS			
202987	Rear indicator lamp assembly		• • • • • • • • • • • • • • • • • • • •	2
17714	Lens, amber	T8/ 1		2
17715	Screw, lens fixing	T8/ 2		4
1771	Washer, lens fixing	T8/ 3		4
1772	Bulb	T8/ 4	• • • • • • • • • • • • • • •	2
17717	Gasket, lens seating	T8/ 5		2
17150	Body	T8/ 6		2
17718	Interior, bulb holder	T8/ 7	• • • • • • • • • • • • • • • • • • • •	2
17719	Grommet, cable entry	T8/ 8	• • • • • • • • • • • • • • • • • • • •	2
17720	Gasket, lamp seating	T8/ 9		2
17695	Nut. lens fixing	T8/10		4
5 05 8 0 B	Nut, lamp fixing		• • • • • • • • • • • • • • • • • • • •	4
51200 B	Lockwasher, lamp fixing	•	•••••	4
202997	Reversing tamp		• • • • • • • • • • • • • • • • • • • •	2
205318	Lens	T8/ 1	• • • • • • • • • • • • • • • • • • • •	2
7715	Screw, lens fixing	T8/ 2	• • • • • • • • • • • • • • • • • • • •	4
17716	Washer, lens fixing	T8/ 3	• • • • • • • • • • • • • • • • • • • •	4
1.7721	Bulb	T8/ 4	• • • • • • • • • • • • • • • • • • • •	2
17717	Gasket, lens seating	T8/ 5	• • • • • • • • • • • • • • • • • • • •	2
17184	Body	T8/ 6		2
17718	Interior, bulb holder	T8/ 7		2
17719	Grommet, cable entry	T8/ 8		2
17720	Gasket, lamp seating	T8/ 9		2
17695	Nut, lens fixing	T8/10		4
506808	Nut, lamp fixing			4
51200B	Lockwasher, lamp fixing			4







PART NO.	DESCRIPTION	PLATE NO.	REMARKS	QTY. REQ.
	INTERIOR LAMP AND COURTESY SWITCH			
202947	Interior lamp assembly			1
16998	Cover	T9/ 1		1
6706	Bulb	T9/ 2		1
16999	Body c.w. switch	T9/3		1
203794	Courtesy switch	T9/4		2
53722B	Screw, lamp and switch fixing	T9/5		8




PART NO.	DESCRIPTION	PLATE NO.	REMARKS	QTY. REQ.
		-		
	INSTRUMENTS AND SWITCHES			÷
204947	Switch, direction indicator	T10/1		1
5715	Relay, direction indicator	T10/ 2		1
53173B	Screw, relay to body	T10/ 3		. 1
511308	Washer, relay to body	T10/ 4		1
204567	Relay, alternator warning light	T10/ 5		1
53173B	Screw, relay to body	T10/3		1
51130B	Washer, relay to body	T10/ 4		1
204538	Switch, horn	T10/ 6		1
200448	Relay, horn	T10/ 7		1
200448	Relay, headlight flasher	T10/8		1
53171B	Screw, relays to body	T10/ 9	·	3
51130B	Washer, relays to body	T10/10		3
204953	Switch, overdrive	T10/11		1
6202	Switch, ignition	T10/12	• • • • • • • • • • • • • • • •	1
202953	Ignition barrel and lock, c.w. keys			. 1
202953	Ignition barrel	T10/13		1
204850	Key	T10/14		2
204582	Tachometer	T10/15		1
200654	Ring, tachometer retaining	T10/18		1
204584	Gauge, oil pressure	T10/17	R.H.D. only	1
205103	Gauge, oil pressure		L.H.D. only	1





PAR NO	DESCRIPTION	PLATE NO.	REMARKS	QTY. REQ.
•	INSTRUMENTS AND SWITCH - continued			
204588	Feed pipe, oil pressure gauge	T10/18	•	,
200628	Washer, oil gauge pressure feed pipe	110/18		' '
204585	Temperature gauge	T10/19		1
204580	Speedometer	T10/20	R.H.D. only	, 1
204581	Speedometer	, 20	L.H.D. only	1
203248	Grommet, speedometer	T10/21		1
200654	Ring, speedometer retaining	T10/22		1
201480	Panel light assembly, push-in			4
201439	Bulb	T10/23		8
201459	Push-in holder	T10/24		4
201479	Panel light assembly, claw			2
201439	Bulb	T10/25		2
201457	Claw holder	T10/26		2
204583	Fuel gauge	T10/27		1
201719	Connection, fued gauge		*************	1
204589	Clock	T10/28		1
170	Bulb, clock	T10/29	• • • • • • • • • • • • • • • • • • • •	1
2045	Ammeter	T10/30	• • • • • • • • • • • • • • • • • • • •	1
17120	Switch, windscreen washer	T10/31	Later vehicles only	1
205421	Escutcheon, washer switch	T10/32		. 1
203742	Escutcheon, washer pump	T10/33		1
17410	Lead, washer switch, earth (black/green)			1
17410	Lead, washer switch, (green)			1
17642	Lucar connection			3
17844	Bullet		• • • • • • • • • • • • • • • • • • • •	2
17647	Snap connector			1
204952	Switch, windscreen wipers	T10/34		1
203444	Switch, head and side lights	T10/35		1
200473	Escutcheon, switch head and side lights	T10/36		1
200373	Cigar lighter assembly			1
205462	Knob/Element assembly	T10/37		1
205463	Element	T10/38		1
17021	Bulb	T10/39		
203444	Switch, heater	T10/40		1
200474	Escutcheon, heater switch	T10/41		1
7886	Dip switch	T10/42	• • • • • • • • • • • • • • • • • • • •	1
51686 <u>B</u>	Screw, dip switch to body	T10/43		2
191	Captive nut, dip switch to body	T10/44		2
2051	Mounting bracket, dipswitch to body	T10/45	L.H.D. only	1 -
205177	Backing plate, mounting bracket to body	T10/46	L.H.D. only	1
52126B	Screw, mounting bracket to body	T10/47	L.H.D. only	4
205009	Switch cover assembly, steering column	T10/48		1
51131 B	Plain washer, switch cover	T10/49	• • • • • • • • • • • • • • • • • • • •	2
51201B	Lockwasher, switch cover	T10/50	• • • • • • • • • • • • • • • • • • • •	2
5-0 7 2:1 B	Nut switch cover	T10/51		2
200810	Push pull control, vacuum – operated windscreen washer	T10/52	Early vehicles	1
200374	Voltage stabilizer		only Not illustrated	1






PART NO.	DESCRIPTION	PLATE NO	REMARKS	REG
	HORN, REGULATOR, FUSES. ALTERNATOR RELAY, SOLENOID, BAT	TERY, COIL		
204488	Horn, high note	T11/ 1		ŕ
204489	Horn, low note			1
203985	Mounting plate, horn	T11/ 2		2
51442B	Set screw, horn fixing	T11/ 3		4
E . 22 · B	Washer, horn fixing	T11/ 4		4
5:00:8	Net horn fixing	T11/5		· 4
204519	Pegalator, voltage control	T11/6	• • • • • • • • • • • • • • • • • • • •	•
51111 5	Screw regulator fixing	T11/7		3
E11238	Master, regulator fuxing	T11/8		5
5 10 00 8	Masher, regulator fixing	T11/ 9		:
506808	Nut. regulator fixing	T11/10	• • • • • • • • • • • • • • • • • • • •	3
5714	Fase unit	711/11		
17278	Cover, fuse unit	T11/12		•
: 7279	Fuse, spare	T11/13		:
17279	Fuse, live	T11/14		:
. 7277	Screw, terminal,	Ť11/15		
52006 B	Screw, fuse unit fixing	T11/16		•
5 1 2 0 B	Washer, fuse unit fixing	T11/17		:
51200B	Washer, fuse unit fixing	T11/18	• • • • • • • • • • • • • • • • • •	•,
50680 B	Nut, fuse unit fixing	T11/19		•
53722 8	Screw, fuse unit fixing	T11/20		
204545	Field relay, alternator	T11/21		•
53173B	Screw, alternator fixing	T11/22		2 -
331730	edian' arrangement and arrangement are arrangement and arrangement are arrange			

T11




PART NO.	DESCRIPTION	PLATE NO.	REMARKS	QTY. REQ.
	FUSES, REGULATOR, HORN, FLASHER UNIT, STARTER SOLENOID, COIL AND BATTERY FIXINGS - continued			
51130B	Washer, alternator relay fixing	T11/23		2
5932	Starter solenoid	T11/24		1.
52122B	Screw, starter solenoid fixing	T11/25		. 2
51130B	Washer, starter solenoid fixing	T11/26		2
51000 B	Nut, starter solenoid fixing	T11/27		2
51202B	Lockwasher, lead to solenoid	T11/28		2
173 41	Nut, lead to solenoid	T11/29		2
203399	Battery	T11/30	• • • • • • • • • • • • • • • • • • • •	2
204734	"U" bolt, battery fixing	T11/31		. 2
51121B	Washer, battery fixing	T11/32		. 4
51201B	Lockwasher, battery fixing	T 11 /3 3		4
5072 1B	Wing nut, battery fixing	T 1,1/34		4
205355	Coil	T11/35		1
206245	Strap, coil fixing	T11/36		1
206246	Screw, strap clamping	T11'/37		1
206247	Lockwasher, clamping screw	T11/38		1
20624	Square nut, clamping screw	T11/39		1
2 0 6 2 4	Bolt, strap fixing	T11/40		1
206250	Lockwasher, strap fixing	T11/41		1
50695B	Nut, strap fixing	T11/42		1





PART NO.	DESCRIPTION	PLATE No.	REMARKS	aty Rea
	WINDSCREEN WASHER			
205286	Washer Kit, electrically operated		Later vehicles	1
205287	Container and pump assembly	• .		1:
205289	Container	T12/ 1		1
205288	Pump and cover	T12/ 2		1
205290	Jet assembly	T12/ 3		2
205291	Tee piece	T12/ 4		1
205292	Plastic tube	T12/ 5		A's
205293	Bracket, container mounting	T12/ 6		1
200886	Washer Kit, vacuum operated		Early vehicles	1
202000	Container and pump assembly			1
202001	Container	T12/ 7		1"
202002	Pump and cover	T12/ 8		1
205205	Jet assembly	T12/ 9		2
200818	Tee piece	T12/10		1
202020	Plastic tube	T12/11		Á s
202010	Bracket, container mounting	T12/12	•••••••••••••••••••••••••••••••••••••••	1
52004B	Screw, container mounting bracket	T12/13	•••••	2
51120B	Washer, container mounting bracket	T12/14		2.
512008	Nut, container mounting bracket	T12/15		2
2272	Grommet, washer tubes			1
3873	Clip, washer tubes			2
53181B	Screw, clip to body			2
51136B	Washer, clip to body			2










PART NO.	DESCRIPTION	PLATE NO.	REMARKS;	OTY.
	SUNSHINE ROOF	ar na della mengalia k	The state of the s	
204804	Main body		Replaces 204789 .	1
204143	Stop, sliding panel	U1/ 1		
51850B	Screw, stop to body	U1/ 2-		2
51130B	Washer, stop to body	U1/ 3		2
51000B	Nut, stop to body	U1/4		ຶ່ງ
203897	Sliding panel	U1/ 5		1
203939	Velvet seal, sliding panel, long	U1/ 8		51
203940	Velvet seal, sliding panel, short	U1/ 7		1 3
2 03887	Plate, lining retaining, centre	U1/ 8:		3
203888	Plate, lining retaining, side	U1/ 9		2
54168K	Rivet, plates, to sliding panel	U1/10	؞ڔ؞ڔ؞؞؞؞؞؞؞؞؞؞؞؞؞؞؞؞؞؞؞؞؞؞؞؞؞؞؞؞؞؞؞؞؞	10
203915	Bracket, sliding panel, L.H	U1/11		31,
203916	Bracket, sliding panel, R.H			1
51400B	Screw, bracket fixing	U1/12		8
9343	Lockwasher, bracket fixing	U1/13		,8
203948	Adjuster base	U1/1,4:	والمراجع والمراجع والمراجع والمراجع والمراجع والمراجع والمراجع	2
203932	Adjuster sleeve	U1/15		2
51843B	Screw, adjuster base fixing	U1 ∕ 1¦8;	•,	4
203917	Guide assembly	U1/17		2
203933	Locating plate	U1/1 ₁ 8		2
	Screw guide assembly	U1/19		*
203991	Trim panel frame c.w. clips	U1/20		1
203913	Cable and guide assembly, L.H	U 1 /2 1		
203914	Cable and guide assembly, R.H	U1/22		1
203920	Bracket, guide	U1/23		2
203992	Screw, guide bracket	U1/24		1
203993	Washer, guide bracket	U 1:/25	e e e e e e e e e e e e e e e e e e e	1
2 03 92 1	Guide rail, R.H.	U-1-/26		7
203922	Guide rail, L.H.	U1/27		*2
203930	Locating pag, guide rail	U1/28 U1/29		2
203927	Corner shim, cable guide			2
203928	Front shim, cable guide	U1/30 U1/31		i
203929	Clip, cable locating	U 1,/31 U:1/32	Manual only	'n
203593	Centre piece, cable guide	0:1/3Z	Electrical only.	1
203925	Centre piece, cable guide	U1/33		2
203938	Side piece, cable guide	U1/33 U1/34		1
203923	Corner piece, L.H. cable guide	U1/35		'n
203924	Corner piece, R.H. cable guide	U1/35 U1/36		2
2 03 9 26	Retaining strip, cable guide	U1/37		16
53061D	Screw, guide ratt tixing	U1/38		2
203949	Ramp	U1/39		2
52921B	Lockwasher, ramp fixing	U1/40		2
9343	Drain tube, 60 inches long	U1/41		2
203950	Drain tube, 38 inches long	9 (7 - 7)		2
203951	Connecting tube, drain tube	U1/42		4
2 03 93 4	Drive	U1/43	Manual only	1
2 03941	Crank arm	U1/44	Manual only	1
203942	Urank afm and an hode	U1/45	Manual only	2
203994	Screw, drive to body	U1/46	Manual only	1
203995		01740		1
203911	Sunshine roof kit, electrical	U1/47		1
203918	Motorised drive	U1/48		1
203894	Mounting bracket, drive	U1/48		1
203919	Switch	U1/50	Part of 203911	
	Fixings, motor		Part of 203911	1
•	Fuse assembly		Part of 203911	1
	Terminal block,			1
205258	Earthing braid			2
205259	Capacitor			1
205260	Connector strip	U1/53		1
205300	Insulation, motor to body		Replaces 203020	1
205443	Headlining		Replaces 205436 7	A 1
9133	Listing rod		nopiacos 200400 1	•
	· · · · · · · · · · · · · · · · · · ·			





PART NO.	DESCRIPITION	PLATE NO.,	REMARKS	QTY. REQ.
			يعوالمحمود بأمي بالمتعمو معن الأفاد المالة	n wangini
	RADIO		•	
204765 204873	Installation kit, radio		U.K. and Europe . Countries except Europe	1
204811 204812	Receiver	U2/ 1	U.K. and Europe . Countries except Europe	g 1 v 1 °
1050°9 105023	Aerial	U2/ 2	U.K. and Europe . Countries except Europe	1
205021	Loudspeaker	U2/ 3		1
236221	Bracket, receiver fixing	U2/ 4		1
52126B	Screw, receiver fixing	U2/ 5	• • • • • • • • • • • • • • • • • • • •	1
50720 8	Wing nut, receiver fixing	U2/ B	• • • • • • • • • • • • • • • • • • • •	1
5 240B	Snakeproof washer, receiver fixing	U2/7	• • • • • • • • • • • • • • • • • • • •	2
50680B	Nut. receiver fixing	U2/-8	· · · · · · · · · · · · · · · · · · ·	1
205222	Washer, receiver fixing	U2/ 9		7
206223	Rond receiver and aerial to chassis	02/10		1 ′
205224	Lead, receiver to battery	U2/11		
206225	Fuse, 1.5 amp	U2/12	• • • • • • • • • • • • • • • • • • • •	. 1
206225	Choke, battery lead	U2/13	• • • • • • • • • • • • • • • • • • • •	1
2052	Lead, receiver to loudspeaker	U2/14		1
204	Bezel, loudspeaker	U2/15	• • • • • • • • • • • • • • • • • • • •	i





PART NO.	BESERIPTION	PLATE No.	REMARKS	\$17. \$68.
	RADIO - continues			
206228	Adaptor boards foudspeaker aggrees	U2/16	் கேற்கே நிறியில் கொள்ளிக்கிர்க்கிரு	1
52123C	Screw, loudspeaker fixings	U2/17	தே கட்டு நக்க கட்டத்தி கி.கி.கி.கி.கி.கி.கி.கி.கி.கி.கி.கி.கி.க	.4
51240B	Washer, foudspeaker fixing	U2/18	வர்கள் இருந்து இருந்த இருந்து இருந்து இருந்த	ુ(4
206229	Sleeve nut, Laudspeaker fixing	U2/19	an a diamenta a diamenta di diamenta	4
206230	Washer, loudspeaker fixing	U2/20	e a a com an a a a a a a a a a a a a a a a a a a	:4
206231	Spring washer, loudsepaker fixing	U2/21 .	e e a e e e e e e e e e e e e e e e e e	4
206232	Sleeve nut, foudspeaker fixing	U2/22	e di e è si	
206233	Screw, aerial firing	U2 /23	a a salaka di salak a di salaka salaka sa	7
206234	Suppression plate, L. W. tylinder Wead	U2/24	age a se se especial se	-31
206235	Suppression plate, R.W. cylinder head	U2/25	நடித்திருள்ளது. அ. அ. அம்முல் இருவிறு வருட்டுக்கு அருக்கிறுள்ளது.	.1
206236	Suppression prate, distributor and coil	U 2/28	െ ഇടുക്കുക്ക് എന്നു വിത്രാക്ക് വരുക്കാര് വരുക്ക്	*1
206237	Bracket, suppression prates;	U2/27	and make the state of the state	*
206238	Bracket, suppression plate, L.H.	U 2 / 28	a a a a a a a a a a a a a a a a a a a	-1
208239	Bracket, suppression plate, front	U2 /2 9	க்கிருந்து இது முறிய முறிய மேற்கு முறிய ம	1
206240	Gronnet beacket	U2/30	ે પ્રાપ્ત કર્યા કર્યું છે. જે તેમ કરવા કરવા કરવા છે. આ આ આ આ આ અને	~1
53743B	Screw, suppression plates fixing	U2/31	ം പ്രധാന വിശ്യാസ് വ	:;•2
51442C	Screw suppression prates fixing	U 2/32	e si	₩2
51500C	Screw such ession distes fixing	U2/33		
51240B	Washer, รษฐมิทิธิรายาที่ plates lixing	u 2/34		2
51241B	Washer, suppression plates fixing	U2 /35		8
51242B	Washer, suppression plates fixing	U2/36		4,
50721B	Wing nut, suppression plates fixing	U2/37		6
+ 1	The following items करने तक्षी हिन्दी आर्थित देशी विदेश हैं के रोडे	fitted:-		
204910	Blanking panel assembly www		Not illustrated .	্ল
204941	Blanking panel		Not illustrated	, 1
204911	Facing: ●数据数		Not illustrated .	্ৰ
205001	Revel hisokings nangi		Not ilkustrated .	.1
507208	Nut blankiwe property fixing		Not ibhustrated.	2
512 00B	Lockwasher, blanking papet fixing		Not illustrated.	2
204943	Washer, blanking panel fixing		Not illustrated .	2





DESCRIPTION

REMARK

QTY. Req.

	HEATED REAR WINDOW	
2 04 2 07 2 0 4 9 3 5	Heated fear window	
8714 204318 17304 204317	Fillerstrip Harness, rear window Switch, rear window Identification disc	only,.,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,
	LAMINATED - W. INDSCREEN	
205104 204935	Laminated windscreen	For use with 2.051.04 1
203499	Fillerstrip	only

